

INDEX

0

100V LINE SPEAKER 06-15, 06-22
 10V TO 6000V CAPACITORS 02-03
 12V
 240V INVERTER 12-50, 18-39
 BATTERY CHARGER 11-33
 BATTERY ISOLATOR 12-51
 BATTERY MONITOR 11-21
 DC TO DC [CAR] 12-45, 18-36
 FLUORO INVERTER 12-51
 UPS 11-33
 WARNING LAMPS 12-56
 WORK LIGHT 14-28
 13.8V POWER SUPPLY 12-35, 12-52
 15V BATTERY 11-04
 2.0 SPEAKERS FOR PC 06-10, 16-11
 2.1 SPEAKER SYSTEM 06-10, 16-11
 2.4 GHz FREQUENCY COUNTER 14-53
 2.4 GHz A/V SENDER 09-13, 20-64
 2.4 GHz WIRELESS CAMERA 21-34
 240V AC MAINS 12-01
 115V TRANSFORMER 12-19
 CABLE 13-14
 CIRCUIT BREAKER 02-27, 12-16
 DOUBLE ADAPTOR 12-09
 EXTENSION CORD LOCK 12-13
 EXTENSION CORDS 12-13
 FUSE WIRE 12-15
 ISOLATION TRANSFORMER 12-33
 LAMPS 12-21
 LEADS 12-12
 OVERSEAS ADAPTOR 12-19
 PLUGS & SOCKETS 12-10
 POWER BOARDS 12-04
 POWER POINTS 12-16
 SAFETY 12-08
 SURGE PROTECTOR 12-06
 SWITCHES 12-16
 TIMERS 12-08
 TRANSFORMERS 12-32
 UPS 12-02
 VARIAC [VARIABLE AC] 14-47
 24V [TRUCK BATTERY]
 240V INVERTER 12-50
 FLUORO INVERTER 12-51
 LAPTOP POWER 12-46
 300 OHM RIBBON CABLE 13-07
 3D CONVERTORS 20-14
 4.433 MHz CRYSTALS 02-16
 5.8 GHz A/V SENDER 09-13
 50 OHM COAX CABLE 13-06
 5000 VOLT FUSES [MWO] 10-13
 6V LANTERN BATTERY 11-04, 11-17, 11-33
 75 OHM COAX CABLE 13-07
 75 OHM TERMINATOR 07-24
 9V BATTERY SNAP LEADS 11-80
 9V SMOKE ALARM BATTERY 11-03

A

AC POWER MAINS 240VAC
 240V TO 115V 12-19
 APPLIANCE LEADS 12-12
 APPLIANCE TEST 10-12, 14-52
 BAYONET LAMP SOCKET 12-17
 BREAKERS PANEL MOUNT 02-27, 12-16
 CABLE 13-13
 CABLE CEILING ROSE 12-17
 CABLE CLIPS 12-18
 CABLE GROMMETS 07-39, 12-15, 13-17
 CABLE SPLICES 07-45, 12-18
 CABLE STRAIN RELIEF 07-39, 12-15
 CABLE TIES & DRESSING 13-15, 18-54
 CABLE TRACE & IDENTIFY 14-61
 CEILING ROSE 12-17
 CIRCUIT BREAKERS 02-27, 12-16
 CLAMP METER 14-55
 DOUBLE ADAPTOR 12-09
 EXTENSION CORD LOCK 12-13
 EXTENSION CORDS 12-13
 FUSE HOLDERS 02-27, 12-16
 FUSE WIRE 12-15
 INPUT SOCKETS 12-14
 JUNCTION BOX 12-17
 LEADS 12-12
 MAINS LAMP DIMMER 12-16
 MOUNTING BLOCKS 07-43, 12-17
 MOUNTING BRACKETS 07-43, 12-17
 PLUGS 12-14
 POWER ADAPTORS DC 12-24, 17-02
 POWER ADAPTORS TRAVEL 12-19
 POWER BOARDS 12-04
 POWER PACKS 12-24
 POWER POINT 07-43, 12-16
 SAFETY PLUG 12-10
 SAFETY SCREWDRIVER 12-54
 SAFETY SWITCH [RCR] 12-08, 12-10
 SOCKET & RECEPTACLES 12-14

SURGE PROTECTOR 12-06, 12-10
 SWITCHES 01-42, 02-29, 10-08, 12-16
 SWITCHPOT 02-15
 TIMER SWITCHES 12-11
 TRANSFORMER 12-21
 UPS 12-02
 VOLTAGE FINDER 14-60
 ACTIVE SPEAKERS 06-07, 06-29
 ACTIVE SPEAKERS PC 16-11
 ADAPTOR CROSS REFERENCE 07-28
 ADAPTORS
 2.5 TO 3.5 HDD 16-18
 AC POWER 12-19
 AC3 07-05
 BALUN [ANTENNA] 09-02
 BATTERY C & D SIZE 11-13
 BNC 07-28
 CAR ACCESSORY POWER 18-36
 CAR AERIAL 18-75
 CB RADIO SSB MARINE 07-25, 19-10
 CD TO CASSETTE 18-36
 COMPUTER 16-08, 16-116, 16-125
 COMPUTER DRIVE MOUNTING 16-20
 DISPLAYPORT 08-07, 16-136
 DVI TO HDMI & VGA 08-05, 16-135
 DVI-D TO DFP20 08-05, 16-135
 F TYPE 07-28, 07-33, 09-02
 FME 07-28, 07-34, 17-24, 19-10
 GAME CONSOLES 15-07
 HARD DISK DRIVE 16-18, 16-21
 HDMI 08-06
 IPOD 08-06, 12-47, 17-47, 18-37
 LUCENT 07-26, 07-29, 16-96
 M1-DA 08-07, 16-137
 M259 & S259 07-28, 07-36, 19-11
 MAINS TRAVEL 12-19
 MCX & MMCX 07-28, 07-32, 19-10
 MEMORY CARD 16-26
 MINI DVI 08-06, 16-136
 MINI TV ANTENNA 07-28, 09-02
 MINI-DISPLAYPORT 08-07, 16-136
 N TYPE 07-28, 07-34, 19-10
 OVERSEAS TRAVEL 07-48, 12-19
 PAL [TV ANTENNA] 07-28, 07-32
 PHONO 07-09, 07-28
 PL259 07-28, 07-33, 19-10
 PLAYSTATION 15-07
 PLAYSTATION CAR POWER 15-05, 18-37
 PROEL AUDIO 07-09
 RCA 07-09, 07-28, 07-38
 RJ45 TO RJ12 SLEEVE 07-41
 S-VIDEO 07-18, 07-29, 07-32, 08-23
 SATA 16-18, 16-21
 SCART TO RCA & S-VIDEO 07-29, 08-12
 SMA 07-28, 07-34, 17-24, 19-10
 TELEPHONE 07-46, 16-102
 TNC 07-28, 07-34
 TOSLINK 08-03
 TRAVEL 07-48, 12-19, 17-12
 TV 07-28, 07-32, 09-02
 USB 16-19, 16-124
 VGA 08-05, 16-115, 16-135
 XLR 07-09, 07-29, 07-31
 ADHESIVE GLUE 14-71
 ADHESIVE TAPE 14-68
 ADJUSTABLE WRENCH 14-19, 18-56
 ADSL
 ACCESSORIES 07-48, 12-10, 16-102
 MODEM & ROUTER 16-54, 16-92
 AEROSOL 14-76
 AIR COMPRESSOR [TYRE PUMP] 18-57
 AIR DUSTER CAN 14-76
 ALARMS 21-36
 ALIGNMENT TOOLS 14-08
 ALKALINE BATTERY 11-03
 ALLEN KEY SCREWS 14-78
 ALLEN KEYS 14-10
 ALLIGATOR CLIP 07-16
 ALLIGATOR CLIP LEADS 14-63
 AMATEUR ANTENNA 19-23
 AMATEUR ANTENNA BASES 19-16
 AMPHENOL CABLES 08-21
 AMPHENOL CONNECTOR 07-04
 AMPLIFIED SPEAKER 06-29, 16-11, 20-62
 AMPLIFIED TV ANTENNA 09-09
 AMPLIFIER
 ANTENNA 09-02
 ANTENNA MASTHEAD 09-18
 CAR 18-03
 EXTENSION SOUND 20-59
 MODULE [AUDIO] 01-26, 06-30
 PUBLIC ADDRESS 06-27
 SATELLITE 09-05, 09-17
 SPEAKER 01-26, 20-15, 20-60
 SUBWOOFER 06-31
 TV ANTENNA 09-02, 09-18
 ANALOGUE
 AUDIO TO OPTIC CONVERT 08-03, 20-16
 MULTIMETER 14-55
 TV PATTERN GENERATOR 03-05, 14-48
 ANSWER MACHINE TAPES 05-20
 ANTENNA
 ACCESSORIES 09-02
 ADAPTORS 07-28, 07-32, 09-02, 19-17
 AMATEUR RADIO CB-SSB 19-23

AMPLIFIED [INDOOR] 09-09
 AMPLIFIER 09-02, 09-17
 AMPLIFIER [MASTHEAD] 09-18
 ATTENUATORS [COMMS] 19-15
 ATTENUATORS [TV RF] 09-02
 BALUN [TV] 09-02
 BASE SPRINGS 19-17
 BASES [CAR COMMS] 19-16
 BOOSTER CAR AM/FM 18-42
 BOOSTER TV 09-02, 09-18
 CABLE / COAX 13-06
 CAR GUTTER MOUNT 19-18
 CAR PLUG / SOCKET 07-39
 CAR RADIO 18-66, 19-20
 CAR TV 19-21
 CAR [MOBILE PHONE] 17-28, 19-31
 CARAVAN [TV / FM] 09-22
 CB 19-23
 CELLULAR 17-28, 19-31
 CORDLESS PHONE 09-09
 COUPLER [TV] 09-03
 DC POWER LEADS 09-20
 DISTRIBUTION AMP 09-17
 DUMMY LOAD [COMMS] 19-15
 FIELD STRENGTH 09-12, 14-50
 FM 09-08, 19-20
 GPS & GSM 17-30, 19-36
 GPS [AUTO] 17-30, 19-34, 19-36
 GUTTER MOUNTS [CAR] 19-18
 HOLE COVER [CAR] 19-17
 INDOOR 09-08
 INPUT SOCKETS [TV]03-02, 07-24, 09-03
 LEADS [TV] 08-29
 LIGHTNING ARRESTER 19-19
 MAGNETIC BASS [COMMS] 19-18
 MARINE 17-33, 19-24
 MOBILE - EXTERNAL 17-28, 19-31
 MOBILE - INTERNAL 17-30, 19-34
 MOBILE 27MHZ VHF 19-25
 MOBILE 477MHZ UHF 19-26
 MOUNTING [AUTO] 19-18
 MOUNTS 19-16
 NEXT-G / GSM 17-28, 19-31
 PANASONIC PHONE 09-09
 PATCH LEADS [COMMS] 08-28, 19-12
 PATCH LEADS [MOBILE] 17-23, 19-12
 PLUG & SOCKET [COMMS] 07-22
 PLUG [TV ANTENNA] 07-23, 09-03
 POWER INJECT / SUPPLY 09-18
 RUBBER DUCKY [PHONE] 09-09
 SCANNER 19-22
 SIGNAL STRENGTH [TV] 09-12, 14-50
 SOCKETS [TV] 03-02, 07-24, 09-03
 SPLITTER [TV] 09-02
 SPRINGS [COMMS] 19-17
 SWITCH 19-15
 SWR & POWER METER 14-50, 19-15
 TELESCOPIC 09-08
 THROUGH GLASS 17-28, 19-33
 TV INDOOR 09-08
 TV INPUT SOCKETS 03-02, 07-24
 TV OUTDOOR 09-22
 VSWR & POWER METER 14-50, 19-15
 WIFI [PC] 16-94, 19-38
 WIRELESS BROADBAND 16-95, 19-32
 WIRELESS NETWORK 16-94, 19-35
 ANTISTATIC ESD
 BAGS FOR COMPONENTS 01-27
 CLEANING LIQUID [SCREEN] 14-72
 EARTH PLUG [240VAC] 14-46
 GLOVES NITRILE & LATEX 14-20
 HEEL STRAP 14-46
 MATS 14-46
 WIPES 14-72
 WRIST BAND 14-46
 APPLE DATA CABLES [PC] 16-116, 16-119
 APPLE DISPLAYPORT ADAPTOR 16-136
 APPLE IPOD iPHONE ACCESSORIES 17-48
 APPLIANCE TESTER 14-52
 ARCHITRAVE SWITCH 12-17
 ARRESTED SURGE & SPIKE 12-04
 ASSORTED SCREW KIT 14-79
 ATTACHE TOOL CASE 14-24
 ATTENUATOR
 ANTENNA [F TYPE] 09-04
 ANTENNA [PAL TYPE] 09-02
 COMMS RF 19-15
 SPEAKER 06-26, 06-49
 AUDIO
 ACOUSTIC REFERENCE 06-48
 AMPLIFIER 01-26, 06-27, 20-15
 ANALOG TO OPTICAL 08-03, 20-16
 BLUETOOTH ACCESSORIES 20-62
 CABLE 13-02
 CABLE [SPEAKER] 13-10
 CASSETTE ALIGNMENT 05-19, 14-67
 CASSETTE TAPES 05-20
 CD ALIGNMENT DISKS 05-19, 14-67
 CD BLANK DISKS 05-20, 16-27
 CONVERTERS 05-22, 08-03, 18-42, 20-16
 CROSSOVER PARTS 06-53, 18-51
 DAT TAPE 05-20, 16-27
 DIGITAL CONVERTERS 05-22, 20-16
 DISTRIBUTION 20-21, 20-60
 EXTENDER 20-23

HEAD CLEANER 05-20
 HEADS 05-05
 IDLERS 05-04
 LEADS 08-02, 08-14
 MICROCASSETTES 05-20
 MICROPHONE INPUT 06-28
 MINI DISKS 05-20, 16-27
 MIXER 05-22, 06-28
 MOTORS 05-06
 OPTICAL TO ANALOG 08-03, 20-16
 PHONO LINE CONVERT 05-22, 20-16
 PINCH ROLLER 05-04
 SPEAKER CROSSOVER 06-51, 18-12
 SWITCHES 20-18
 SYNCHRONISER 20-16
 VOX SWITCH 06-28

AV

CABLE 13-04
 CAPTURE TO USB 16-14, 16-16
 CONVERT TO XGA 15-14
 CONVERTORS 09-16, 20-66
 DISTRIBUTION 20-21, 20-24
 LEADS 08-02, 08-16, 08-22
 LEADS [HI QUALITY] 08-22
 LEADS [NINTENDO] 15-02
 LEADS [PLAYSTATION] 15-07
 LEADS [XBOX] 15-09
 OVER CAT5 20-57
 SENDER 09-13, 20-64
 SWITCH BOX 20-18, 20-30
 WALL PLATES 07-40, 09-06, 20-58
 WIRELESS SENDER 09-13, 20-64
 AVIATION STYLE HEADSET 06-08, 16-10
 AXIAL LAMPS 02-21

B

BACK-SHELLS 16-113
 BACKUP BATTERIES 11-18
 BAGS PLASTIC 01-27
 BALUN
 LINE [RCA TO XLR] 07-02
 MASTHEAD 09-03
 TV 09-02
 BANANA PLUGS & SOCKETS 07-16
 BAND SEPARATOR UHF-VHF 09-02
 BASES [ANTENNA] 19-13, 19-16
 BASS REFLEX PORT 06-50, 18-12
 BATTEN HOLDER LAMP 12-17
 BATTERY
 ALARMS 11-04
 BACKUP 11-06, 11-18
 BIG JIM 6V 11-04
 BUTTON 11-08
 BUTTON [TAGGED] 11-09
 CAMCORDER 11-34
 CAMERA [DIGITAL STILL] 11-46
 CARBON 11-02
 CHARGERS 12-35, 12-44, 12-52
 CHARGERS 11-10, 11-32, 17-02
 CLAMP CAR 18-48
 COMPUTER 11-06
 CORDLESS PHONE 11-22
 DRY [9V] 11-04
 ELIMINATOR [240V TO 12V] 12-35
 GAMEBOY 11-51, 15-12
 GPS 11-56
 HEARING AID 11-08
 HOBBY PACK 11-20
 HOLDERS 11-80
 IPOD 11-52
 ISOLATOR [CAR] 12-51, 18-38
 LANTERN 11-04
 LANTERN RECHARGEABLE 11-17
 LAPTOP 11-60
 LEADS [9V] 11-80
 LITHIUM 11-04
 MANGANESE 11-02
 MEDIA PLAYER 11-53
 MERCURY 11-07
 MONITOR [12VDC] 11-33
 NICAD CONSUMER 11-15
 NIMH CONSUMER 11-12
 NINTENDO 11-51, 15-12
 PAGER 11-04
 PDA & PALM 11-54
 PLAYSTATION PS3 11-51, 15-12
 PLAYSTATION PSP 11-51, 15-12
 POWER SOLDER IRON 14-31
 POWER TOOL 11-68
 RACING 11-20
 RECHARGEABLE 11-11
 SEALED LEAD ACID 11-28
 SIZE C & D ADAPTOR 11-13
 SMOKE ALARM 11-03
 SNAP LEADS 11-80
 TADIRAN 11-06
 CD BLANK DISKS 05-20, 16-27
 CONVERTERS 05-22, 08-03, 18-42, 20-16
 CROSSOVER PARTS 06-53, 18-51
 DAT TAPE 05-20, 16-27
 DIGITAL CONVERTERS 05-22, 20-16
 DISTRIBUTION 20-21, 20-60
 EXTENDER 20-23

- BATTERY CHARGERS**
CAMCORDER 11-34
CAMCORDER REFERENCE 11-38
CAR 12V 11-33, 12-52
GENERAL PURPOSE 11-10, 11-32
HOBBY - RACE CAR 11-21
POWER TOOL 11-79
SEALED LEAD ACID 11-28
- BEAD INDUCTOR** 02-17
BEARING GREASE 14-71
- BELT**
AUDIO 05-02
MICROWAVE 10-14
VIDEO 04-08
- BEZEL LAMP** 02-20
BIKE LAMPS 12-56
- BLADES**
HACKSAW 14-16
JIGSAW 14-80
RETRACTABLE KNIFE 14-15
- BLANK DISKS** 05-20, 16-27
BLANK TAPES 05-20
BLANKING WALL PLATE 09-05, 12-16
BLOW TORCH 14-29
BLU-RAY CASE 16-31
BLU-RAY DISKS 16-29
BLU-RAY DRIVE 16-20
- BLUETOOTH**
AUDIO 20-62
CAR KITS 17-31
EARSETS [MOBILE PHONE] 17-19
HANDS FREE KITS 17-05
HEADPHONES 06-07, 16-90, 17-19
HEADSET 16-10, 17-19
KEYBOARD 16-06
MOUSE 16-03
USB DONGLE 16-17
SPEAKERS 06-30
- BNC**
ADAPTORS 07-28
CRO LEAD 14-63
END CAP 07-38
ETHERNET 16-111
LEADS 08-28, 16-111
PLUG & SOCKET 07-22
TERMINATOR 07-22
- BOAT WHIP ANTENNA** 19-24
BOLTS & NUTS 14-78
BOLTS & NUTS [TRANSISTOR] 01-29
BOOKS & SERVICE MANUALS 01-28, 14-66
BOOKSHELF SPEAKERS 06-12, 06-58
BOOSTER ANTENNA 09-02
BOTTLE FOR DISPENSING 14-43
BOX [FOR TOOLS] 14-24
BOXES JIFFY 02-36
- BRACKET [MOUNTING]**
CAMERA ARMS 21-30
COMMS ANTENNA 19-18
LCD & PLASMA MOUNT 20-92
MARINE ANTENNA 19-25
MICROWAVE SUPPORT 20-99
MOBILE PHONE 17-16, 18-16
SPEAKER 06-47, 20-99
TV SUPPORT 20-98
WALL PLATE 240V 12-17
- BREADBOARD** 01-28
BRIDGE RECTIFIERS 01-31
BRUSHES [CLEANING] 14-74
BRUSHES [PAINT] 14-74
BULBS [LAMPS] 01-34, 02-20, 12-27, 14-26
BULL BAR ANTENNA MOUNT 19-19
BULLET CONNECTOR 07-45, 18-40
BURNER [CD/DVD/BLU-RAY] 16-20
BUTANE SOLDER IRON 14-29
BUTTON BATTERY 11-07
BUTYL RUBBER TAPE 14-68
BUZZERS 06-54, 21-41
- C**
CABLE MANAGEMENT 13-15, 16-83, 20-97
CABLE [ALSO SEE LEADS]
100V PA LINE 13-05, 13-10
12V 13-08
300 OHM RIBBON 13-07
50 OHM COAX 13-06
75 OHM COAX 13-07
AC MAINS 13-14
AGGREGATE [MULTICORE] 13-05, 13-13
ALARM 13-05, 13-14
ANTENNA 13-06
AUDIO 13-02
AUTOMOTIVE 13-08
AV 13-04
CAMERAS [SECURITY] 13-05
CAR KIT 13-09
CAT5 & CAT6 13-12, 16-106
CLAMPS [CHASSIS MOUNT] 13-17
CLIPS 13-15
CLOTH COVERED 01-39, 13-08
COAX [AUDIO] 13-02
COAX [RF] 13-06
COAX [SECURITY] 13-05
COMMUNICATION 13-06, 13-14
- COMPUTER ETHERNET** 13-12, 16-106
COMPUTER FLAT IDC 13-13, 16-112
COMPUTER MULTI-CONDUCTOR 13-13
CONNECTORS 07-01
CURLY CORD 13-14, 19-02
DATA 13-12
DROP HOOD [WALL] 07-43, 09-05
ETHERNET 13-12, 16-106
FLAT WIRE CONNECTS 05-09
FLAT [SPEAKER] 06-127, 13-11
GENERAL PURPOSE 13-10
GROMMETS 13-17
HARNESS [CAR] 18-58
HEAT SHRINK TAPE 13-19, 14-68
HEAT SHRINK TUBING 13-18
HEAVY DUTY AUTOMOTIVE 13-08
HOLDERS 13-15
IDC 13-13, 16-112
IDENTIFIER & TRACING 14-61
LOCKING 21-39
LOOM TUBING [AUTO] 13-17
MAINS 13-14
MICROPHONE 13-03
MICROPHONE [CURLY] 13-14
MODULAR 13-14
NETWORKING 13-12, 16-106
PHONE 13-14
POWER 12-15, 13-14
PULLERS & PULLING 14-22
RGB 13-05
RIBBON - COMPUTER 13-13
RIBBON - FLAT WIRE 05-09
RIBBON - TV [300 OHM] 13-07
S-VIDEO 13-04
SECURITY 13-05
SPEAKER 06-127, 13-09, 18-35
SPEAKER [100V LINE] 13-10
SPIRAL WRAP 13-17
STAND OFFS 13-15
STRAIN RELIEF 13-17
STRIPPER 14-15
TELEPHONE 13-14
TELEPHONE HANDSET 07-46
TESTING & TRACING 14-61
TIE MOUNTS 13-15
TIE TOOL 13-15, 14-09
TIES 13-15
TV ANTENNA 13-07
TWISTED PAIR 13-20
VGA [AGGREGATE] 13-05
VIDEO 13-04
VINTAGE CLOTH 01-39, 13-08
WRAP 13-16
- CALIPER VERNIER** 14-25
CAMCORDER
BATTERIES 11-34
BATTERY CHARGERS 11-34
CHARGER REFERENCE 11-38
LEADS [BREAKOUT] 08-24
LEADS [DIGITAL] 08-26, 16-126
POWER SUPPLY 12-44
- CAMERA**
2.4GHZ WIRELESS 21-34
ARMS & SUPPORTS 21-30
BATTERY 11-04, 11-40, 11-50
BOX & BULLET TYPE 21-22
CABLE [SECURITY] 13-05
CASES 16-33
CLOTH [LENS] 14-73
CONTROLLERS 21-10
CUBE TYPE 21-32
DOME 21-12
DOOR 21-03
DUMMY 21-29
EXTENSION LEADS 21-44
HOUSING 21-23
INSPECTION 21-08
IP 16-12, 21-24, 21-27
LENS 21-23
MINIATURE 21-35
OUTDOOR 21-16, 21-26
PAN-TILT-ZOOM [PTZ] 16-12, 21-10, 21-24
REVERSING [CAR] 18-23, 21-21
SECURITY 21-01
SPY HOLE 21-21
TRIPOD AND SPIRIT LEVELS 16-32
WEBCAM 16-12
WIRELESS 21-24, 21-34
- CAPACITORS** 02-02
BACKUP 11-18
CAN TYPE 01-39, 02-12
CAR AUDIO STIFFENING 18-36
CERAMIC 02-03
CROSS-OVER 02-04, 06-52, 18-51
ELECTROLYTIC 01-39, 02-04
FEED THRU 02-17
GOLD [BACKUP] 02-12, 11-18
MAINS RATED 02-07
METAL CAN 01-39, 02-08
METALLISED POLYPROP 02-04
MICROWAVE 10-14
NON POLAR 02-08
POLYESTER 02-06
POLYPROPYLENE 02-04
SILVER MICA 02-04
- SOLENOID POLYPROP** 02-04
SURFACE MOUNT 02-11
TANTALUM 02-05
TESTING METER 14-57
TRIMMER 02-03
TUNING 02-03
- CAR AUDIO**
ACCESSORY ADAPTORS 18-36
ACCESSORY BATT CHARGER 11-10
ACCESSORY JACK & PLUG 07-19, 18-50
ACCESSORY LEAD 07-19, 12-47, 18-35
AMPLIFIER 18-03
ANTENNA 18-66
ANTENNA ADAPTORS 07-39, 18-75
ANTENNA BOOSTER 18-75
ANTENNA INPUT LEAD 07-39
ANTENNA MOUNTING 19-18
ANTENNA PLUGS & SOCKETS 07-39
CABLE KITS 13-09, 18-32
CASSETTE ADAPTOR 05-21
CIGAR LIGHT PLUG 07-19, 18-50
CROSSOVER PARTS 18-51
FLOATING GROUND ADAPTOR 18-42
FM MODULATOR 17-12, 18-43
GAME POWER [PS2] 15-07
GAME POWER [PSP] 15-05
GAMEBOY POWER 15-03
GASKET TAPE 14-69, 18-13
GROUND LOOP ISOLATER 18-42
HARNESS [GENERAL] 18-58
HARNESS [SPECIAL] 17-05
IN DASH MOUNT KITS 18-15
IPOD POWER LEAD 12-47, 18-37
ISO CONNECTS 18-59
KIT [CABLE] 13-09, 18-33
LCD MOUNT BRACKETS 18-22
MOBILE PHONE MOUNT 17-10, 18-16
MP3 FM MODULATOR 17-12, 18-43
PLASTIC PLATE 18-13
POWER CABLE KITS 13-09, 18-32
QUICK DISCONNECT 07-50, 18-58
RADIO HARNESS 18-58
RADIO SERVICE TOOLS 18-56
SOUND PROOFING 06-50, 18-13
SPEAKER > RCA CONVERTER 18-42
SPEAKER ADAPTOR 18-08
SPEAKER Baffle 18-09
SPEAKER BOXES 18-10
SPEAKER GRILLE 18-13
SPEAKER INTERRUPTER 18-45
SPEAKER SPACER 18-08
SPEAKERS 06-57, 18-02
STEREO HARNESS 18-58
SUB-WOOFER CROSSOVER 18-12
SUB-WOOFERS 06-58, 06-64, 06-119
SUB-WOOFERS 18-02, 18-04
USB POWER PACK 12-47, 17-13, 18-37
WIRING HARNESS 07-50, 18-45, 18-58
- CAR-AUTOMOTIVE**
12V DC TO DC CONVERTER 18-36
12V TO 240VAC INVERTER 18-39
24V-12V CONVERTER 18-38
ACCESSORY LEAD 18-37
ACCESSORY PLUG & JACK 18-50
ACCESSORY SPLIT 18-37
AIR COMPRESSOR 18-57
ALLIGATOR CLIPS 07-17, 18-49
ANTENNA 18-66
ANTENNA ADAPTORS 18-42, 18-75
ANTENNA BOOSTER 18-42, 18-75
ANTENNA GPS 17-30, 19-34, 19-36
ANTENNA MOUNTING 18-76, 19-18
ANTENNA PLUG & SOCKET 07-39, 18-75
BATTERY CHARGER 11-33, 12-52
BATTERY ISOLATOR 12-51, 18-38
BATTERY TERMINAL 18-48
BLUETOOTH ACCESSORIES 17-06
CABLE 13-08, 18-32
CABLE ADAPTORS 18-48
CABLE CONNECT 07-01, 18-32, 18-40
CABLE HOLDERS 18-53
CABLE KITS 18-32
CABLE SPLITTERS 18-48
CABLE TIES & WRAP 18-54
CAPACITORS 18-36
CB ANTENNA BASES 19-16
CIRCUIT BREAKER 18-47
DISTRIBUTION BLOCK 18-47
FM TRANSMITTERS 18-43
FUSE 02-23, 18-46
FUSE HOLDER 02-27, 18-46
GAFFA TAPE 14-68, 18-53
GPS & GSM ANTENNA 19-36
GPS ANTENNA 19-34
GSM ANTENNA 19-31
HANDS FREE [MOB PHONE] 17-05
HARNESS [GENERAL] 18-58
HARNESS [SPECIAL] 17-05
HOSE CLAMPS 13-20, 18-55
IGNITION FILTER 18-36
IMPACT WRENCH 18-57
INDICATOR & DIAL LAMPS 02-20, 18-41
INTERIOR LIGHTS 18-30
ISO CONNECTORS 18-59
LCD MONITORS 18-24
- LIGHTING ACCESSORIES** 18-28, 18-57
MASKING TAPE 18-53
NEXT-G/3G ANTENNA 19-31, 19-36
NOISE SUPPRESSOR 18-36, 19-07
NUTS & BOLTS 14-79, 18-53
ORNAMENTAL LIGHTING 18-30
PHONE BRACKETS 18-16
PHONE HOLDERS 18-16
POWER ADAPTORS 12-47, 18-37
QUICK DISCONNECT 18-40, 18-58
RELAY 02-28, 18-41
REVERSE SENSING KIT 18-27
REVERSING CAMERAS 18-23, 21-32
RING TERMINALS 18-40, 18-48
SCREWS 18-21, 18-52
SPADE CONNECTOR 18-40, 18-49
SWITCH 02-35, 18-50
SYSTEM CONVERTER 18-44, 20-66
TAIL STRAPS 18-74
TERMINALS 18-40, 18-58
TV TUNER (CAR) 18-44
USB ACCESSORIES 18-37
- CARBON**
BATTERY 11-02
RESISTORS 02-14
TUNING TRACKS 03-02
CARLING SWITCH 02-35
- CARRY CASE TO SUIT**
CD & DVD 05-21, 16-31
DIGITAL/VIDEO CAMERA 16-33
LAPTOP & NOTEBOOK 16-34
MICROPHONE 06-43
MULTI-METER 14-55, 14-59
PLAYSTATION PSP 15-04
TOOL BOX 14-11, 16-79
- CARTRIDGE [TURNTABLE]**
MOUNTING 05-23
REPLACEMENT 05-26
STYLUS 05-26
WIRES 05-23
- CASE**
ATTACHE 14-24
CD & DVD STORAGE 05-21, 14-24, 16-30
GPS 17-22
IPAD 17-42
IPOD iPHONE 17-36
MOBILE PHONE 17-36
MULTIMETER 14-55
PSP 15-04
TOOL 14-11, 14-24, 14-79
- CASSETTE**
AUDIO TEST 05-19
BELTS 05-02
CD CAR ADAPTOR 05-21
DAT AUDIO 05-20
HEAD CLEANER [AUDIO] 05-20
HEADS 05-05
IDLERS 05-04
MICRO-AUDIO 05-20
MICROPHONE 06-37
MOTORS 05-06
PINCH ROLLERS 05-04
TEST TAPE 05-19
TEST TAPE [VCR] 04-24
- CAT5/e & CAT6/e**
ADAPTORS 16-102
BOOTS 16-108
CABLE 16-106
CONNECTOR PLUGS 16-108
CRIMPING TOOL 14-14, 16-107
CROSS-OVER ADAPTOR 16-103
CROSS-OVER LEAD 16-105
DUPLER MODULE 16-109
ETHERCON XLR 16-109
KEYSTONE 16-109
KRONE TOOL 16-107
LEADS 16-104
MOUNTING BOXES 16-109
PATCH LEADS 16-105
PLUGS 16-104
PUNCH DOWN TOOL 16-107
SURFACE MOUNT 16-109
TESTER 16-79
WALL PLATES 16-109
- CAULKING GUN** 14-19
- CB**
24V TO 12V REDUCER 19-07
ACCESSORIES 19-02
ANTENNA BASES 19-16
ANTENNA CABLE 19-14
BRACKET 19-18
GUTTER MOUNT 19-18
IGNITION SUPPRESSOR 19-07
LEADS POWER 19-07
LEADS RF 19-12, 19-16
MAGNETIC BASE 19-18
MARINE ANTENNA 19-24
MICROPHONE 19-02
PLUGS & SOCKETS 19-02, 19-08
POWER 19-07
SPEAKER EXTENSION 19-06
SPRINGS [ANTENNA] 19-17
SWR & POWER METER 19-15
TAIL STRAP 19-17
VOLTAGE REDUCER 19-07

- CD
ALIGNMENT 05-19
BELTS 05-02
BLANK MEDIA 05-20, 16-27
CASE 05-21, 16-30
CLEAN & REPAIR KITS 05-18, 05-24
DISKS 05-20, 16-27
DOOR CATCHER 05-06
DRIVES 16-20
ENVELOPES CD COVERS 05-21
FLAT CABLE CONNECTOR 05-09
JEWEL CASE 05-21
LABELLING 16-30
LASER DECK CUSHION 05-09
LASER POWER METER 05-19, 14-53
LENS CLEANER DISK 05-19, 14-67
LOADING BELTS 05-02
MEMBRANE CONNECTOR 05-09
MINI CDR 05-20, 16-27
MOTORS 05-08
PLAYER LASER CLEANING 05-19
RE-WRITEABLE DISKS 05-20, 16-27
REPAIR KIT 05-18, 14-67
SLEEVES 05-21, 16-30
STORAGE 05-21, 16-30
TEST DISK 05-19, 14-67
TO CAR CASSETTE ADAPT 05-21, 18-36
WALLET [STORAGE] 05-21, 16-31
- CD & DVD DRIVES 16-20
CD & DVD LASERS 05-10
CEILING CUTTER 14-15, 14-81
CEILING ROSE 12-17
CEILING SPEAKER 06-15
CELLULAR PHONE MIC 06-37, 17-05
- CENTRONICS
LEADS 16-121
PLUGS 16-113
USB CONVERTER 16-18, 16-121
- CERAMIC
CAPACITORS 02-03
FILTER 02-17
FUSE 02-23
RESONATOR 02-16
TRAP 02-17
- CF MEMORY CARD 16-26
CHAMOIS CLEANER SWABS 14-75
- CHARGERS [BATTERY]
CAMCORDER 11-34
CAMCORDER REFERENCE 11-38
GAME 15-02, 15-11
GENERAL 11-10, 11-33
HOBBY - RACE CAR 11-21
LEAD ACID 11-33
MOBILE PHONE 17-02, 17-10
POWER TOOL 11-79
SLA 11-32
- CHOKES RF 02-13
CIGARETTE LIGHTER PLUG 07-19, 18-50
- CIRCUIT
BOARD [VERO-BOARD] 01-28
BREAKER AUTOMOTIVE 18-47
BREAKER PANEL MOUNT 02-27, 12-16
INTEGRATED 01-12
PROTECTORS 02-23
CLAMP SCISSOR 14-09
CLAMPS [HOSE] 13-20
CLARION CAR STEREO PARTS 05-04
CLAW HAMMERS 14-19
- CLEANING
BRUSHES 14-74
CD 05-18, 05-24, 14-67, 14-72
CLOTHS 05-18, 05-24, 14-72
DISKS [CD/DVD PLAYER] 05-19, 14-67
DVD 05-18, 14-67
SOLUTION 05-18, 14-72
STRIPS & SWABS 05-18, 14-75
VINYL RECORDS 05-24
WIPES 14-72
- CLOCK [DIGITAL TRAVEL] 12-11
CLOTH COVERED WIRE 01-39, 13-08
CLOTH WIPES 14-72
- COAX CABLE
50 OHM & 75 OHM 13-06
AUDIO 13-02
CLIPS 13-15
COMMUNICATION 13-06
JOINER 07-24
MICROPHONE 13-03
PRE-MADE 19-12, 08-28
RG & LL 13-06, 19-12
SECURITY 13-05, 21-44
STRIPPER TOOL 14-15
TIES 13-15
VIDEO 13-04, 13-07
WRAP 13-16
- COCHLEAR IMPLANT BATTERY 11-08
COILS 02-13, 03-03, 06-53
- COMBINATION TOOL SETS
GENERAL 14-11
SCREWDRIVER 14-03
SQUARE & LEVEL 14-25
UNIVERSAL MINI 14-06
- COMMUNICATION
24V-12V CONVERTER 18-38, 19-07
ACOUSTIC EAR TUBE 19-03
- ADAPTORS 07-28
ANTENNA BASES 19-16, 19-25
ANTENNA COAX 13-06
ANTENNA MOUNTS 19-18, 19-25
ANTENNA PATCH LEADS 19-12, 19-16
ANTENNA SWITCH 19-15
ATTENUATOR 19-15
CABLE 13-06, 19-14
CB ACCESSORIES 19-02
CONNECTORS 07-22, 07-38, 19-08
DUMMY LOAD 19-15
H ACCESSORIES 19-03
HEADSETS 19-04
LEADS 08-28, 19-12, 19-16
LIGHTNING ARRESTER 19-19
MICROPHONES 19-02
POWER LEADS 19-07
POWER SUPPLY 12-35, 19-07
SPEAKER 06-55, 19-06
VSWR & POWER METER 14-50, 19-15
- COMPONENT TRAYS 14-24
COMPONENT VIDEO [See YUV]
CABLE 13-04, 13-07
LEADS 08-15, 08-22
COMPOUND HEAT 14-70
SILICON 16-71
COMPRESSOR [AIR] 18-57
- COMPUTER
ADAPTORS D-PLUGS 16-115
ADSL ACCESSORIES 07-49, 16-102
ADSL ROUTERS 16-100
APPLE LEADS 16-116, 16-119
BATTERY [BACKUP] 11-06, 11-18
BATTERY [LAPTOP] 11-60
BATTERY [PDA] 11-54
BLANK DISKS 16-27
BLU-RAY DRIVE 16-20
BLUETOOTH 16-90
BNC ETHERNET 16-111
CABLE [COAX] 13-06, 16-96
CABLE [IDC] 16-112
CABLE [MONITOR] 13-05, 16-133
CABLE [MULTI CORE] 13-13
CARDS 16-49, 16-93, 21-48
CD & DVD DRIVES 16-28
CD & DVD LABELS 16-30
CD & DVD MEDIA 16-27
CENTRONICS 16-113
CLEANING 16-76
COOLING FANS 16-68
D-TYPE PLUG 16-113
D9/D15/D25 WALL PLATES 16-112
DATA SWITCH BOXES 16-56
DESK MICROPHONE 16-12, 16-101
DRIVE MOUNTING 16-20
DVD DISKS 16-28
DVD LABELS 16-30
DVI LEADS 16-133
DVR CARDS & KITS 16-14, 16-55
ETHERNET 16-84, 16-142
ETHERNET CABLE 16-106
ETHERNET CARD 16-54
ETHERNET PRINT SERVER 16-85
EXTERNAL CD/DVD CASES 16-21
EXTERNAL CD/DVD DRIVE 16-20
EXTERNAL FDD 16-20
EXTERNAL HDD CASES 16-21
FAN 16-68
FAN CPU COOLERS 16-68
FAN GUARDS 16-71
FAN HARD-DRIVE 16-68
FAN POWER LEADS 16-71
FIBRE OPTIC NETWORK 16-88
FIREWIRE ADAPTORS 16-130
FIREWIRE CARD 16-130
FIREWIRE LEADS 16-130
FLOPPY DISKS 16-27
FLOPPY DRIVE 16-20
GAMEPAD 16-08
GENDER CHANGERS CAT5 16-103
GENDER CHANGERS D 16-115
GENDER CHANGERS USB 16-125
HARD DISK COOLING 16-68
HARD DISK DRIVES 16-25
HARD DISK EXTERNAL 16-21
HARD DISK IDE SATA LEADS 16-47
HARD DISK JUMP CONNECT 16-48
HARD DISK MOBILE RACKS 16-21
HARD DISK MOUNTING 16-20
HARNESS POWER & MOLEX 16-47
HDD & PCB JUMPER PLUGS 16-48
HDD ADAPTORS 16-18
HEADSET W/ MIC 16-10
HEATSINK COMPOUND 16-71
HEATSINK [PC & CPU] 16-68
HUBS USB 16-56
IDC CABLE & PLUGS 16-112
IDC CRIMP PLUG 16-112
IDC CRIMP TOOL 16-78
IDC PUSH TOOL [KRONE] 14-15, 16-78
IDE LEADS 16-49
IEEE-1394 PCI/e CARDS 16-53, 16-130
IP CAMERAS 16-13, 21-22
IRDA TO USB TRANSCIEVER 16-16
JOYSTICK & GAMEPAD 16-08
- JUMPER CONNECTS 16-48
KEYBOARD 16-04
KEYBOARD ADAPTOR 16-08, 16-116
KEYPAD ADD-ON 16-08
KVM - KEYBOARD-VIDEO-MOUSE 16-58
KVM EXTENDER 16-61
KVM MINI 16-58
LAN CABLE TESTER 16-79
LEADS ETHERNET 16-105
LEADS NETWORK & CAT5/6e 16-105
LEADS OPTICAL FIBRE 16-88
LEADS POWER AC & UPC 16-44
LEADS SCSI 16-118
LEADS USB 16-121, 16-128
LEADS WIFI ANTENNAE 16-96
MACINTOSH II TO PRINCETON 16-132
MEDIA CENTRE REMOTE 16-09
MEDIA NAS SERVER IN-A-BOX 16-23
MEDIA [BLANK] 16-27
MEMORY CARD READER 16-16
MEMORY CARDS 16-26
MICROPHONE 16-12
MIDI USB & BREAK-OUT LEAD 16-131
MODEM CONNECT LEADS 16-103
MODEM [DIAL UP] 16-54
MOLEX POWER ADAPTOR 16-46
MONITOR ADAPTORS 16-115, 16-135
MONITOR CABLE 16-133
MONITOR DVI LEADS 16-133
MONITOR SELECT SWITCH 16-56
MONITOR SUPPORT STAND 16-39
MONITOR VGA LEADS 16-132
MOUSE 16-02
MOUSE ADAPTOR LEAD 16-116
MOUSE PAD 16-02
MULTIMEDIA BREAK OUT BAYS 16-20
NAS 16-22
NETWORK CABLING CAT5/6e 16-106
NETWORK TEST/TRACE 16-79
NETWORK WiFi 16-93
NUMERIC KEYPAD ADD-ON 16-08
PARALLEL DATA CABLES 16-120
PATA TO SATA 16-48
PATCH LEADS CAT5/6e 16-104
PC-VGA TO TV CONVERT 20-83
PCB CONNECTORS & MOUNTS 16-113
PCB SHUNT JUMPERS 16-48
PCI / PCIe CARDS 16-49, 16-53, 16-93
PCMCIA CARDS 16-52, 16-84
PLUGS RJ45 CAT5/6e 16-103, 16-108
POE [power over ethernet] 16-86
POWER ADAPTORS 16-45, 16-49
POWER BOARDS 240AC 12-04, 16-42
POWER CHECK 16-45
POWER CORDS 240AC 12-12, 16-44
POWER LAPTOP 12-44, 16-37
POWER LEAD HDD 16-48
POWER LEAD MOLEX 16-48
POWER PROTECTION 16-40
POWER SUPPLY ATX 16-45
POWER UPS 16-40
PRINTER LEADS 16-121
PRINTER SERVER 16-85
PS2 ADAPTOR & LEAD 16-116
PS2 KVM 16-116
REMOVABLE HDD RACK 16-21
RF REMOTE PRESENTER 16-09
RJ45 TOOLS 14-14, 16-78
RS232 ADAPTORS 16-120, 21-10
RS232 EXTENDER 16-66, 20-52
RS232 LEADS 16-120
SAS CABLES 16-50
SATA & eSATA CABLES 16-47
SATA POWER ADAPTORS 16-46
SATA TO PATA 16-48
SCANNER [HAND HELD] 16-08
SCREW KIT 16-112
SCSI ADAPTOR 16-117
SCSI LEADS 16-118
SCSI PLUGS 16-113
SERIAL LEADS 16-18, 16-120
SIM PLATE KEYSTONE 16-110
SOLID STATE DISK 16-25
SOUND CARD [PCI] 16-55
SPEAKERS 06-10, 16-11
SSD [SOLID STATE DRIVE] 16-25
SUN-MICRO LEAD 16-132
SURGE PROTECTION 12-04
SWITCH PC ATX POWER 16-45
SWITCH SELECT BOXES 16-56
TESTER CAT5/6 NETWORK 16-79
TESTER POWER 16-45
THERMAL CONTROL LAPTOP 16-36
TOOLS 14-11, 16-78
UPS 12-02, 16-40
USB ACCESSORIES 16-14, 16-122
USB ADAPTOR 16-18, 16-102
USB BOOSTER/EXTENDER 16-122
USB FLASH DRIVE 16-27
USB HUBS 16-16
USB LEADS 16-121
USB SOCKET 16-114, 09-07
USB TO SATA 16-18
USB TRAVEL KIT 16-123
VGA EXTEND & SPLITTER 16-60, 20-42
- VGA LEADS 16-132
VGA SWITCHING 16-61, 20-22
VIDEO CARD 16-55
VOIP 16-101
WALL PLATE 07-41, 09-05, 16-109
WEBCAM 16-12, 21-24
WIFI ANTENNA & CABLES 07-26, 16-94
WIRELESS NETWORKING 16-92
IPOD IPHONE CONNECT 16-124
- CONCRETE DRILL SET 14-81
- CONDUCTIVE
GREASE 14-70
SILVER PAINT 14-44
CONDUIT CUTTER 14-15
- CONNECTORS 07-01
AMPHENOL/CANNON 07-04
AUTO QUICK DISCONNECT 07-50, 18-58
CABLE 07-01, 12-18, 18-40, 18-49
CAT5/6e 16-108
COMMUNICATION 07-09, 07-22, 07-38
DC POWER 07-20
DEANS 1300 ULTRA 11-21
FLAT WIRE 05-09
FUTABA 11-21
JR 11-21
SPADE TERMINAL 07-17, 07-45, 18-40
TAMIYA 11-21
XLR 07-02, 08-21
- CONTACT CLEANER & LUBE 14-70, 14-76
- CONTROLLER
PLAYSTATION 15-06
SECURITY SYSTEM 21-10
XBOX 15-10
- CONTROLS [REMOTE] 20-10
- CONVERTER
AUDIO TO DIGITAL 08-03, 20-16
CAMERA TO WIRELESS 21-35
COAX TO OPTICAL 08-03, 20-16
COLOUR SYSTEM 20-66, 20-90
DC-DC [CAR] 12-45, 18-36
DIGITAL AUDIO 08-03, 20-16
DISPLAYPORT 20-67
DVI 20-70
HDMI 20-74
LINE TO PHONO 05-22, 20-16
OPTICAL TO COAX 08-03, 20-16
PAL TO NTSC 20-90
PHONO TO LINE 05-22, 20-16
RF MODULATOR [GAME] 09-13, 15-07
S-VHS TO SCART 07-32, 08-12, 08-23
SDI 20-68
SPEAKER TO RCA LINE 06-48, 18-42
USB TO E-SATA 16-18
USB TO ETHERNET 16-18
USB TO HDMI 16-14, 20-51
USB TO PARALLEL 16-18
USB TO SERIAL 16-18
VIDEO SCALER 20-82
VIDEO TO XGA 15-14
- COOLING FANS 16-68
- CORDLESS
HEADPHONES 06-05, 06-09
PHONE ANTENNA [PANA] 09-09
PHONE BATTERY 11-22
SCREWDRIVER 14-03
- CORE INDUCTOR 03-03
COTTON BUDS / TIPS 14-75
GLOVES 14-20
SWABS 14-75
- CRADLE MOBILE PHONE & GP HOLDER 17-10, 18-16
- CRIMP
COMMUNICATION PLUGS 07-24, 17-24
ETHERNET PLUGS BNC 07-22, 16-111
ETHERNET PLUGS RJ45 16-108
TOOLS 14-12
CRIMP PLUG FERULES [RG58/59] 07-27
CRT PROBES 14-62
CROCODILE CLIPS 07-16
CROCODILE LEADS 14-63
- CROSSOVER PARTS
COMPONENTS 02-01, 06-51, 18-51
SPEAKER 06-48, 06-51, 18-12, 18-42
- CRT DEGAUSSER 03-05, 14-47
CRT SOCKET 03-04
CRT YOKE 03-04
CRYSTALS 02-16
CUBE SPEAKER 06-11
CURLY CORD 13-14, 19-02
CURLY CORD [TELEPHONE] 07-46, 16-103
CUT OFF [THERMAL] 02-18, 02-23, 10-12
CUTTING KNIVES 14-15
- CYPRESS
3D CONVERTER 20-14
AUDIO CONVERTORS 20-16
AV SELECTORS 20-18, 20-30, 20-36
EXTENDERS 20-42
FORMAT CONVERTERS 20-66
MATRIX 20-20, 20-36, 20-54
SPEAKERS AND AMPS 20-15
SPLITTERS 20-21, 20-24
SWITCHES 20-19, 20-30
SWITCHING SPLITTERS 20-34
TV WALL 20-14

D

DAB+ 20-07
 DA-SACK BUM BAG 17-43
 DAT AUDIO TAPES 05-20, 16-27
 DC
 12V UPS 11-33, 12-52
 24V TO 12V REDUCER 18-38
 CONVERTERS [CAR] 18-36
 PLUGS & SOCKETS . 07-19, 12-38, 12-48
 POWER CABLE 13-08, 13-14
 POWER LEADS 07-20, 07-50, 12-48
 POWER PACKS 12-34
 POWER SUPPLIES 12-37
 DEANS ULTRA CONNECTS 11-21
 DECADE BOX 14-59
 DEGAUSSING WAND 03-05, 14-47
 DELAY LINE [TV] 03-02
 DENTIST MIRROR 14-26
 DESK LAMP 12-20, 14-27
 DESK MICROPHONE 06-37, 16-12, 19-02
 DESK STAND MAGNIFIER 12-20, 14-27
 DESK TAPE DISPENSER 14-68
 DESOLDER
 AID TOOLS 14-44, 14-74
 FUME EXTRACTOR 14-42
 PISTOL / STATION 14-39
 SMD REMOVAL 14-44
 SUCKERS / WICK 14-45
 DIAL CORD 05-06, 13-17
 DIEMEN TRANSFORMERS 03-10
 DIGITAL
 AUDIO CONVERTERS 05-22, 20-16
 CAMCORDER LEADS 08-26, 16-126
 CAMERA BATTERY . 11-04, 11-34, 11-46
 CAMERA INTERCONNECT . 8-26, 16-126
 CAMERA LENS CLEANER 16-33
 CAMERA SCREEN PROTECTOR 16-33
 CAPACITANCE / LCR METER 14-57
 CLOCK [TRAVEL] 12-11
 COAX LEADS 08-02, 08-14, 08-22
 MEDIA CENTRES 20-02
 MULTI-METERS 14-54
 PHOTO FRAME 16-15
 RADIO 20-07
 RF SIGNAL METERS 09-12, 14-50
 SET TOP BOX 20-07
 STUD FINDER 12-54, 14-60
 TAPES 05-20, 16-27
 THERMOMETER 12-11, 14-51
 TIMER [AC POWER] 12-11, 21-39
 TOSLINK LEADS 08-02
 TV TUNER [USB] 16-17, 16-54
 DIMMER LIGHT [240VAC] 12-16
 DIN LEADS 08-19, 16-131
 DIN PLUGS & SOCKETS 07-15, 07-18
 DIODE 01-32, 10-09
 BRIDGE 01-31
 FLASHING 01-34
 INFRA-RED 01-34
 LED 01-34
 MICROWAVE 10-09
 PACK 01-31
 PHOTO 01-33, 04-21
 ZENER 01-31
 DIPLEXER
 INLINE 09-02
 MASTHEAD 09-03, 09-21
 DIPOLE ANTENNA 09-08
 DISK
 BLURAY 16-29
 CASE & CARRY SOLUTIONS 16-30
 CD-R MUSIC [BLANK] 05-20, 16-27
 CD-R/RW [BLANK] 05-20, 16-27
 CLEANERS 14-67, 14-72
 CLEANING DISKS 14-67
 DRIVE [CD / DVD BURNER] 16-28
 DRIVE [FLOPPY] 16-20
 DVD-R/RW [BLANK] 16-28
 FLOPPY DISK 16-27
 LABELS 16-30
 MINI [BLANK] 05-20, 16-27
 STORAGE 05-21, 14-24, 16-30
 DISPENSER BOTTLE & PEN 14-43
 DISPENSER STICKY TAPE 14-68
 DISPLAY TURNTABLE [POS] 17-43
 DISPLAYPORT
 ADAPTORS 08-07, 16-136
 CONVERTERS 20-66
 LEADS 08-07, 16-136
 SPLITTER 20-24
 DISTRIBUTION
 AMP RF POWER 09-18, 09-20
 AMP RF RACK MOUNT 09-17
 AMP RF ANTENNA 09-17
 AMP SATELLITE 09-05, 09-17
 AUDIO - VIDEO 20-60
 AV 20-21, 20-65, 20-59
 AV SWITCH BOXES 20-18, 20-30
 BLOCK AUTOMOTIVE 18-48
 IR 20-54, 20-59
 DIVERS TORCHES 12-58
 DJ MIXERS 05-22, 06-28
 DOME CAMERAS 21-12, 21-24

DOOR

CAMERA 21-03
 CATCH [TV/CD/VCR] 02-33
 INTERCOM 21-02
 LINING [MICROWAVE] 10-07
 LOCKING CATCH 02-33, 21-03
 STRIKE OPENER 21-03
 SWITCHES [MICROWAVE] 10-08
 DOORWAY BEAM / EYE 21-42
 DOUBLE ADAPTOR 240V AC 12-09
 DOUBLE POWER PSP 15-05
 DOUBLE SIDED TAPE 14-69
 DRILL
 BIT KITS 14-81
 BITS 14-80
 CHUCK 14-81
 DUBBING KIT [VCR] 08-28
 DUCT TAPE 14-68
 DUMMY LOAD RESISTOR 02-16, 19-15
 DUST BLOW 14-76
 DUST-GO CLOTH 14-73
 DVD
 BELTS 05-02
 CASE & HOLDERS 05-21, 16-30
 CLEANING KIT 14-67, 14-72
 DISKS 16-28
 DRIVE [PC] 16-20
 FLAT WIRE CONNECTS 05-09
 LABELLING 16-30
 LASER POWER METER 14-53
 LENS CLEANER 14-67, 16-76
 LIGHTSCRIBE DVD -R+R 16-28
 MEDIA 16-28
 MOTORS 05-08
 RAM DISKS 16-29
 STORAGE 16-30
 TEST DISK 14-67
 VIDEO STABILISER 20-90
 DVD & CD LASERS 05-10
 DVI
 ADAPTOR PLUGS/LEADS . 08-05, 16-134
 BOOSTER/REPEATER 16-62, 20-44
 CONVERTER 20-70
 LEADS 08-04, 16-133
 SCALERS 20-72
 SPLITTERS 08-05, 16-62, 20-25
 SWITCHES 16-63, 16-67
 WALL PLATE 07-41, 16-112
 DVR
 ADAPTOR PLUGS/LEADS . 08-05, 16-134
 BOOSTER/REPEATER 16-62, 20-44
 CONVERTER 20-70
 LEADS 08-04, 16-133
 SCALERS 20-72
 SPLITTERS 08-05, 16-62, 20-25
 SWITCHES 16-63, 16-67
 WALL PLATE 07-41, 16-112
 E
 EAR
 BUDS & PHONES 06-06, 17-20
 MUFFS & PLUGS 06-02, 14-21
 PADS 06-04, 06-09
 PIECE 06-07
 EHT
 CD LISTING 03-08
 LEAD 03-07
 PROBE 03-08
 TESTER 03-06
 TRANSFORMER 03-03, 03-10
 TRIPPLER 03-06
 ELECTROLYTIC CAPACITORS 02-08
 ELECTRONIC TOOL WALLET 14-11
 EMI FERRITE CORES 02-17
 ENERGY SAVING LAMP 12-21
 ENTRY
 ALARMS & MONITORS 21-02, 21-36
 DOOR STRIKE 21-03
 KEYPAD 21-40
 ETHERNET
 CABLE CAT5E / 6 13-12, 16-106
 CARD PCI INSIDE PC 16-54
 CARD PCMCIA CARD 16-52
 HUBS 16-84
 KEYSTONE 07-42, 16-109
 LEADS CAT5/6e 16-104
 PLUGS 16-108
 RACK PATCH PANEL 16-82
 SOCKETS 07-48, 16-109
 SWITCH [RACK MOUNT] 16-80
 TOOLS 14-14, 14-58, 16-78
 USB 16-84
 ETHYLENE GLYCOL COOLANT 03-09
 EXTENDER / BOOSTER
 DVI 16-62, 20-23, 20-44
 HDMI 16-64, 20-50
 HDMI OVER CAT5 20-45
 REMOTE CONTROL 09-14, 20-54
 VGA 16-60, 20-22, 20-44
 EXTENSION
 CAR ACCESSORY LEAD 07-19, 18-36
 CAR ANTENNA CABLE 18-75
 COMPUTER LEADS 16-116
 CORD LOCK [240VAC PLUG] 12-13
 CORDS [240VAC] 12-13
 LEADS [240VAC] 12-1212-13
 LEADS - GAME 15-07
 LEADS - USB 16-122
 LEADS - VGA 16-132
 POWER CORDS - AC 240V 12-13
 TELEPHONE CABLE 07-46, 16-103

EXTERNAL

CD / DVD DRIVE 16-28
 FLOPPY DRIVE 16-20
 HARD DISK DRIVE 16-21
 MEDIA SERVER BOX 20-02
 EXTRACTOR
 FUME EXHAUST FAN 14-42
 F
 F TYPE
 ADAPTORS 07-28, 07-33, 09-02
 ATTENUATOR 09-04
 BOOSTER 09-02, 09-18
 COUPLER 09-04
 ENTRY BOX 09-04
 FLY LEADS 08-29
 MASTHEAD BALUN 09-03
 PLUGS & SOCKETS 07-24, 09-04
 SATELLITE LINE AMP 09-05, 09-17
 SPLITTER [SATELLITE] 09-04
 SPLITTER [TV] 09-04
 TERMINATOR 75 OHM 07-24, 09-04
 WALL PLATE 07-43, 09-04
 FANS
 COMPUTER 16-68
 EXTRACTOR 16-83
 FINGER GUARDS 16-71
 GENERAL PURPOSE 16-70
 FARADAY ANTISTATIC BAGS 01-27
 FAULT MANUALS 14-66
 FBT TESTER 14-47
 FBT [MONITOR & TV] 03-03, 03-10
 FEED THRU CAPS 02-17
 FEET [RUBBER] 06-48
 FEET [SPEAKER SPIKES] 06-48
 FENDER TRANSFORMERS 01-40
 FERRITE
 BEAD INDUCTORS 02-17
 CAP FILTER 02-17
 CORES 02-17, 12-14
 FET
 FIBRE OPTIC AV LEADS 08-02
 FIBRE OPTIC NETWORKING 16-88
 FIBRE PCB CLEANING PEN 14-74
 FIELD STRENGTH METER 09-12, 14-50
 FILTER
 ADSL PHONE LINE 07-49, 16-102
 CAPS 240V MAINS 02-07
 CERAMIC 02-17
 EMI CORES 02-17, 12-14
 FM MAST MOUNT 09-21
 FIREWIRE
 ADAPTORS 16-130
 BOOSTER 16-130
 LEADS 16-130
 PCI & PCI-e CARD 16-130
 PCMCIA & EXPRESS CARD 16-130
 FLASH DRIVE [USB] 16-27
 FLASHING
 DIODE 01-34
 LIGHTS [12VDC] 18-30
 MOBILE PHONE ITEMS 17-43
 FLAT BELTS 05-02
 FLAT WIRE CONNECTS 05-09
 FLOPPY DISK BLANK 16-27
 FLOPPY DISK CLEANER 16-76
 FLOPPY DISK DRIVE 16-20
 FLUORESCENT
 CAR WORK LIGHT 14-28, 18-30
 INVERTER 12V & 24V 12-51
 LAMP STARTER 12-26
 LAMPS 12-20
 FLUX [SOLDERING] 14-43
 FLYBACK TRANSFORMERS 03-03, 03-10
 FLYWHEEL PHILIPS CASSETTE 05-04
 FM FILTER MAST MOUNT 09-21
 FM INDOOR ANTENNA 09-08
 FM WIRELESS MIC 06-39
 FME
 ADAPTORS 07-34
 CABLE & LEADS 17-23, 19-12
 PLUGS & SOCKETS . 07-26, 17-25, 19-08
 FOAM
 CLEANING SWABS & TIPS 14-75
 GASKET TAPE 14-69
 FOCUS [TV]
 POT 03-02
 RESISTORS 03-02
 FOOT SWITCH 02-31
 FORMAT CONVERT [VIDEO] 09-16, 20-66
 FOUNTEK TWEETERS 06-76
 FOXTEL CABLES 08-12, 20-13
 FOXTEL EXTENDER 20-13
 FOXTEL REMOTES 20-13
 FREEZE SPRAY 14-76
 FREQUENCY COUNTER 14-53
 FRIDGE LAMPS 02-22, 10-10
 FUME EXTRACTOR [SOLDERING] 14-42
 FUSE
 ATC / ATM / ATS 02-23
 AUTOMOTIVE 02-23, 18-46
 CERAMIC 02-23, 10-13
 CIRCUIT PROTECTOR 02-23

CUT OFF 02-18, 02-23, 10-12
 GENERAL 02-18
 HOLDER [CAR] 18-46
 HOLDERS 02-27, 12-16
 HRC 02-23, 10-13
 LAMPS 02-20, 18-41
 MICRO 02-23
 MICROWAVE 10-13
 PICO 02-23
 POLYSWITCH 02-19, 06-53
 REMOVER TOOL 02-27
 SEMICONDUCTOR 02-23
 SHATTER PROOF 02-23, 10-13
 THERMAL [CUTOFF] 02-18
 WIRE [240VAC] 12-15
 FUSIBLE RESISTOR 02-14
 FUTABA CONNECTOR 11-21

G

GAFFA TAPE 14-68
 GAME
 ADAPTORS 15-07
 AV SELECTOR 20-18
 BATTERY [NINTENDO] 11-51, 15-12
 BATTERY [PS3] 11-51, 15-07
 BATTERY [PSP] 11-51, 15-05
 BATTERY [XBOX] 11-51, 15-12
 CAR CHARGERS 15-03, 15-07, 18-37
 CAR POWER ADAPTOR 18-37
 CARRY CASE [NINTENDO] 15-02
 CARRY CASE [PSP] 15-04
 CLEANING SYSTEM 15-04
 COMPUTER ACCESSORIES 16-122
 CONTROLLER [NINTENDO] 15-02
 CONTROLLER [PC] 16-08
 CONTROLLER [PS1 & PS2] 15-06
 CONTROLLER [XBOX] 15-09
 GAMEPAD TO PC 15-07
 LASER [PS] 15-08
 LASER [XBOX] 15-10
 LEADS [GAME BOY] 15-03, 18-37
 LEADS [NINTENDO] 15-07, 18-23
 LEADS [PSP TO USB] 15-05, 17-47
 LEADS [PS] 15-07, 16-37
 LEADS [WII] 15-02
 LEADS [XBOX] 15-07
 MEMORY CARD PSX 15-07
 MEMORY STICK [PSP] 15-04
 MOTOR [PS] 05-08, 15-08
 NINTENDO 15-02
 POWER PSP 11-51, 12-35
 POWER SUPPLY DS & GB 12-35, 15-03
 POWER SUPPLY PSX/PS2 15-07
 PSP ACCESSORIES 15-04
 RF CONVERTER 15-07, 15-10, 15-13
 SPARE PARTS 15-08, 15-10
 STANDS [PS2] 15-07
 STARTERS KIT [PS2] 15-06
 STARTERS KIT [PSP] 15-04
 STEERING WHEEL [XBOX] 15-09
 VGA CONVERTER 15-14
 WII ACCESSORIES 15-02
 WIRELESS CONTROLLER 15-09
 X-BOX ACCESSORIES 15-09
 GAMEBOY BATTERIES 11-51, 15-12
 GAMEPAD [PC] 16-08
 GAMEPAD [PS] 15-06
 GAMEPAD [XBOX] 15-10
 GAS DC SURGE ARRESTOR 02-17
 GAS SOLDER IRON 14-29, 14-32
 GASKET TAPE 14-69
 GENDER CHANGERS 07-01
 COMPUTER 16-115, 16-135
 MINI DIN 07-18
 TELEPHONE 07-46, 16-103
 GENERATOR - TV TEST PATTERN 14-48
 GLASS FUSE 02-23
 GLASSES & GOGGLES 14-21
 GLOBES 02-20, 10-10, 12-20
 GLOVES 14-20
 GLUE GUN 14-29
 GLUES 14-71
 GOOSE NECK
 CRADLE [PDA/PHONE] 17-10, 18-16
 LAMP 14-26, 14-28
 MICROPHONES 06-39, 06-41
 MIRROR 14-26
 SCREWDRIVER 14-04
 GPS ACCESSORIES 11-59, 16-90, 17-22
 GPS ANTENNA 17-31, 19-37
 GPS BATTERIES 11-56
 GREASE & LUBES 14-70, 14-76
 GRILLE
 SPEAKER CLIPS 06-50
 SPEAKER CLOTH 06-50, 18-13
 SPEAKER [CAR] 06-67, 18-13
 SPEAKER [CEILING] 06-24, 06-67
 GROMMETS 07-39, 13-17
 GROUND LOOP ISOLATOR 06-28, 21-44
 GUITAR
 LEAD 06-36, 08-19
 MIC 06-39
 SPEAKER 06-46, 06-64, 06-74

GUNS
 CABLE TIE 13-15, 14-09
 CAULKING 14-19
 HEAT 14-29
 HOT GLUE 14-29
 POP RIVET 14-19, 14-79
 GUTTER MOUNT CB BASE 19-18
 GYROCK SAW 14-15, 14-81

H

H - MIC PLUG & ACCESSORIES 19-03
HACKSAW & BLADES 14-16
HAKKO SOLDERING 14-36
HALOGEN LAMPS 12-27
HAMMER 14-19
HAND ASSIST TOOLS 14-10, 14-44, 14-74
HANDS FREE
 CAR KIT 17-05, 18-16
 PERSONAL 06-07, 17-21
HARD DISK DRIVE
 EXTERNAL 16-21
 INTERNAL 16-25
 MOUNTING 16-20
HARD HATS 14-21
HARNES, CAR 18-58
HD SET TOP BOX 20-07
HD15 OVER CAT5 20-42
HDMI
 ADAPTORS 08-06
 ANALYZER / TESTER 14-49
 BOOSTER/EXTENDER 16-64, 20-50
 CONVERTERS 20-17, 20-66
 LEADS 08-08, 16-138
 MATRIX 20-38
 OVER CAT5/CAT6 20-45
 OVER COAX 20-49
 OVER OPTICAL FIBRE 20-49
 REPEATER 20-50
 SPLITTER 20-23, 02-26
 SWITCHES 20-31
 WALL PLATES 07-41
HEAD
 AUDIO 05-05
 CLEANING CASS TAPE 05-20
 CLEANING SWABS 14-75
 DRUM ASSEMBLY [VCR] 04-02
 VCR [VIDEO] 04-02
HEAD CLEANER
 CHAMOIS & SWABS 14-75
HEAD EXTRACTOR [VCR] 04-05, 14-10
HEADPHONE
 BLUETOOTH 06-07, 16-91, 17-19
 COMPUTER 16-10
 CORDLESS 06-05, 06-09
 EARBUDS 06-06, 17-20
 EARPAD 06-04, 06-09
 GENERAL 06-03
 INFRARED 06-05
 USB 16-10
 XBOX 15-11
HEADS
 VCR [VIDEO] 04-02
HEADSETS 06-07, 16-10
HEARING AID BATTERY 11-08
HEAT GUN 14-29
HEAT SHRINK TAPE 13-19
HEAT SHRINK TUBING 13-18
HEAT TRANSFER COMPOUND 14-70
HEEL STRAP ANTISTATIC 14-46
HERBIE CABLE CLIPS 13-20
HEX KEY SET 14-10
HEX LOCKING SETS 16-112
HEX TIP DRIVERS & BITS 14-04
HIGH VOLTAGE
 CAPACITOR [MWO] 10-14
 DIODE [MWO] 10-09
 FUSE [MWO] 10-13
 LEAD 03-07
 PROBE 14-47
 TRANSFORMER [TV] 03-03, 03-10
HOBBY BATTERY PACK 11-20
HOLDER
 BATTERY 11-80
 FUSE 02-27, 18-46
 MICROPHONE 06-36, 06-40, 19-02
 MOBILE PHONE 17-10, 18-16
HOLE SAW & CUTTER 14-81
HOME SECURITY 21-02, 21-37
HOOK UP WIRE 13-10
HORN
 100V SPEAKER 06-24
 MID RANGE 06-75
 PA SPEAKER 06-55, 19-06, 21-41
 PUBLIC ADDRESS 06-35
 TWEETER 06-75
HOSE CLAMPS 13-20, 18-55
HOT GLUE GUN 14-29
HOUSING
 CAMERA 21-23
 VIDEO CASSETTE 04-26
HUB [ETHERNET] 16-84
HUB [USB] 16-16, 16-56
HV PROBE 14-47

I

IBM 3179 H/V LEAD 03-07
IC
 COMPONENT LISTING 01-12
 EXTRACTOR 01-27, 14-44
 PINS 01-30
 REWORK TOOLS 14-30
 SOCKETS 01-30
 TOOLS 14-30
IDC & IDE PLUGS DVI 16-112
IDC RIBBON CABLE 13-13, 16-112
IDC TOOL 14-15
IDLER
 AUDIO 05-04
 TYRE [AUDIO] 05-04
IEC POWER LEADS 240VAC 12-12
IEC POWER PLUGS/SOCKETS 12-14
ILLUMINATED MAGNIFIER 14-26
IMPACT WRENCH CAR 18-57
INDOOR ANTENNA [TV/FM] 09-08
INDUCTION MICROPHONE 06-37, 07-47
INDUCTOR
 COMPONENTS 02-13
 MAGNETIC CORE - TV 03-03
 SPEAKER CROSSOVER 06-53, 18-51
INFRA-RED
 DIODES COMPONENT 01-34
 DIODES ILLUMINATION 21-28
 DISTRIBUTION IR 20-36, 20-53, 20-59
 REPEATER/EXTENDER 09-14, 20-53
INNER DOOR LINING [MWO] 10-07
INSPECTION CAMERAS 14-82
INSTRUMENT LEADS 06-36, 08-21
INSTRUMENTAL MIC 06-39
INSTRUMENTAL SPEAKER 06-74
INSULATED SCREWDRIVER 14-02
INSULATION
 METER TESTER MEGA-OHM 14-61
 TAPE 14-68
 WASHERS [IC] 01-29
INTEGRATED CIRCUITS 01-03, 01-12
INTERCOM [VIDEO] 21-02
INTERCOM [WIRELESS] 12-10
INTERNET TV BOX 20-04
INVERTER
 12V/24V TO FLUORO 12-51
 12V/24V TO 240V 12-50, 18-39
IP CAMERAS [INTERNET PROTOCOL] 21-24
IP CAMERAS [INGRESS PROTECTED] 21-14
IRDA 16-16, 17-47
ISO CONNECTS [AUTO] 18-59
ISOLATION TRANSFORMER 240 14-47
ISOLATOR, CAR BATTERY 12-51, 18-38
ISOPROPANOL CLEANING FLUID 14-72
iPOD
 ADAPTORS AUDIO 07-30
 ADAPTORS VIDEO OUT 08-06
 BATTERY REPLACEMENT 11-52
 CABLES & LEADS 08-07, 08-20, 08-25
 CABLES & LEADS 16-122, 17-47, 18-37
 CAR CHARGER 12-47, 18-37
 CHARGERS 12-35, 17-02
 VIDEO LEADS 08-07, 08-25

J

JEWELLER SCREWDRIVER 14-07
JIFFY BOXES 02-36
JIGSAW BLADES 14-80
JOYSTICK
 COMPUTER LEAD 16-131
 COMPUTER PC 16-08
JR CONNECTORS 11-21
JTS BRAND MICROPHONES 06-40
JUMPER LEADS ALLIGATOR 14-63
JUNCTION BOX 240VAC 12-17

K

KEYBOARD
 COMPUTER 16-04
 CONTROLLER FOR PTZ 21-11
 LEADS - PC 16-116
KEYPAD
 ENTRY [SECURITY] 21-40
 NUMERIC [PC] 16-08
 REPAIR KIT 14-70
KEYSTONE FOR PC 16-109
KICK SWITCH 01-42, 02-31
KITS
 CAMERA & MONITOR 21-02, 21-34
 CAR AUDIO POWER 13-09, 18-32
 CLEANING 14-72
 HOT GLUE GUN 14-29
 PC ACCESSORIES 16-123
 QUICK DISCONNECT 18-40
 SCREWS 14-79
 SPEAKER 06-122
 TOOL 14-11, 14-29, 14-81
KNIFE [BOX CUTTERS] 14-15

KNOB

ASSORTED 01-42, 02-29
CHICKEN HEAD 01-42, 02-29
TEMPEST & PALSONIC 03-08
KVM ENTERPRISE 16-57
KVM EXTENDER OVER CAT5 16-61
KVM LEADS 16-132
KVM SWITCH 16-59

L

LABELS [TAMPER PROOF] 14-69
LAMP BALLAST [SAMSUNG] 03-09
LAMPS
 BICYCLE 12-56, 14-28
 DIVERS 12-58
 FLUORESCENT 12-20
 FRIDGE 02-22, 10-10
 GENERAL 02-22, 10-10
 INSPECTION 14-26
 MAGNIFYING 14-27
 MICROWAVE 10-10
 MINERS 12-56, 14-28
 PATHWAY LIGHTS 12-09
 QUARTZ HALOGEN 12-27
 SAMSUNG & SONY 03-09
 SEWING MACHINE 02-22
 TORCHES 12-56, 14-28
LANTERN BATTERY 11-04, 11-17
LAPEL MIC
LAPTOP & NOTEBOOK
 ACCESSORIES 16-34
 BATTERY 11-60
 CAR POWER 12-45
 CARRY CASES 16-34
 CD DRIVE 16-20
 DVD DRIVE 16-20
 FLOPPY DRIVE 16-20
 HDD & SSD 16-25
 POWER PACKS 12-43
 STAND 16-36
 SECURITY 21-39
 USB FDD & CD/DVD DRIVE 16-20
LASER
 ALIGNMENT DISKS 14-67
 CD & DVD 05-10
 GAME CONSOLE [PS] 15-08
 GAME CONSOLE [XBOX] 15-10
 LENS CLEANER 05-18
 LEVELLING TOOL 14-25
 POWER METER 14-53
LCD
 BACK LIGHT TESTER 03-18, 14-47
 MONITOR BRACKETS 20-104
 MONITORS 18-25, 21-09
 MONITORS [CAR] 18-24
 MOUNT BRACKETS [AUTO] 18-22
 REVERSING MONITORS 18-26, 21-33
 SCREEN CLEAN 14-72, 16-76
LCD & LDP PROJECTOR
 BALLAST 03-09
 LAMPS 03-09
LEAD LAMPS 02-20, 18-41
LEADS
 75 OHM [TV] 08-28
 AC POWER 12-12
 AMPHENOL 06-36, 08-21
 ANTENNA [TV] 08-29
 ANTENNA [WIFI] 16-96, 19-12
 CAMERA BREAKOUT 08-24, 16-126
 CAR ACCESSORY POWER 12-47, 18-36
 CAR ANTENNA 07-39, 18-75
 CB 19-07, 19-16
 COMMUNICATION 08-28, 19-12, 19-16
 COMPONENT VIDEO 08-12, 08-15, 08-22
 COMPUTER ETHERNET 16-105
 COMPUTER MONITOR 08-13, 16-132
 COMPUTER POWER 12-12, 16-44
 COMPUTER USB 16-121
 COMPUTER WIFI 16-96, 19-12
 DC POWER 07-20, 12-48
 DIGITAL AUDIO 08-02
 DIGITAL CAMERA 08-24, 08-26
 DIN LEADS 08-19, 16-131
 DISPLAY PORT 08-07, 16-136
 DVI 08-04, 16-134
 DVI-A TO VGA 08-05, 16-133
 DVI-D TO DFP20 08-05, 16-135
 DVI-D TO HDMI-A 08-05, 16-135
 EHT 03-07
 FIREWIRE 16-130
 FME 19-12
 HDMI 08-08
 HIGH VOLTAGE TV 03-07
 IPOD & IPHONE 06-09, 08-07, 16-124
 LUCENT 17-23
 MIDI 08-19, 16-131
 MULTIMETER 14-62
 MUSICAL INSTRUMENT 06-36, 08-21
 N 17-23, 19-12
 NINTENDO 15-02
 OFC RCA 08-14, 08-16, 08-22
 OPTICAL FIBRE 08-02
 OSCILLOSCOPE PROBES 14-62

PHONO [RCA] 08-01, 08-18
PLAYSTATION 15-07
POWER [AC] 12-12
POWER [DC] 18-32, 18-58
RGB LEAD 08-13, 16-133
S-VIDEO 08-15, 08-23
SCART LEAD 08-12, 08-15
SMA 17-23, 17-26
TELEPHONE 07-46, 16-102
TOSLINK 08-02, 20-18
TV COAX FLYLEADS 08-14, 08-29
USB 16-121
VGA 08-13, 16-132
VIDEO 08-01, 08-22, 08-28
VIDEO CAMERA 08-24
VIDEO DUB KIT 08-28
WHITE PEARL 08-14
WIFI 16-96, 19-12
WII 15-02
XBOX 15-09
LEARNING REMOTES 20-10
LEAD
 COMPONENT 01-34
 CAR INTERIOR LIGHTS 18-31
 FLASHING 01-34
 IR EMITTER 01-34
 IR SPOTLIGHT 21-28
 LIGHT STRIPS FOR CARS 18-29
 LIGHTING 12-28
 PANEL CLIPS & BEZELS 01-34, 18-41
 SUPER BRIGHT 01-35, 12-28
 TORCHES 12-56
 TRI-COLOURED 01-34
LENS CLEANER [CAMERA] 14-72
LENS CLEANER [LASER] 14-67
LEVEL ONE - FULL LISTING 16-142
ADSL MODEM 16-100
CAMERA IP COMPACT 16-12, 21-24
CAMERA IP PTZ 21-13
CAMERA IP SURVEILLANCE 21-26
ETHERNET CARDS PCI/e 16-54
ETHERNET HUB / SWITCH 16-84
FIBRE OPTICS 16-89
LISTING 16-142
NAS NVR 21-64
WIFI ANTENNA 19-38
WIFI DINGLE 16-17
WIFI ROUTER & ACCESS POINT 16-92
LIGHT
 AUTOMOTIVE 18-28
 GLOBES [APPLIANCE] 02-22, 10-10
 GLOBES [ASSORTED] 02-20
 HALOGEN DOWN LAMPS 12-27
 MAGNIFIER LAMPS 14-26
LIGHTING 12-09
LIGHTNING ARRESTER "N" 19-19
LINE OUTPUT TRANSFORMER 03-03, 03-10
LINE TRANSFORMER
 100V PA 06-24
 RCA TO RCA 18-42
 RCA TO XLR BALUN 07-02
 SPEAKER TO RCA 18-42
 VALVE TUBE REVERB 01-40
LITHIUM BATTERY 11-05
LL195 COAX CABLE 13-06
LL400 COAX CABLE 13-06
LOADING BELTS [CD & DVD] 05-02
LOCKING
 CATCH TV & VCR DOOR 02-33
 PAINT [SCREWS] 14-70
LOCKS
 CABLE & PADLOCK 21-39
 CAM BARREL KEY 21-40
 DOOR SENTRY 21-40
 DOOR VIDEO 21-02
 KEY SWITCH 21-40
 LOCTITE GLUE 14-71
 LOGIC PROBE 14-61
 LOGIC PULSER 14-61
 LOOK-C INTERCOMS 21-02
LOPT
 COMPUTER MONITOR 03-17
 TELEVISION 03-03, 03-10
 TESTER 03-06, 14-47
LUBRICANTS & GREASE 14-70, 14-76
LUCENT ADAPTOR LEAD 17-23, 19-12
LUCENT PLUG [WIFI] 07-26
LUMINANCE DELAY LINE TV 03-02

M

M1-DA 08-07, 16-137
M259 & S259 MINI UHF
 ADAPTORS 07-36, 17-24, 19-11
 PLUGS & SOCKETS 07-27, 17-25, 19-08
MAGNETIC
 BASE CB/UHF 19-18
 GPS ANTENNA 19-36
MAGNETIC SHIELDED SPEAKER
 COMPUTER 06-10, 16-11
 DAI-1CHI SPEAKER 06-30
 DAI-1CHI DRIVER 06-62
 TV 06-56
 VIFA 06-99

- MAGNETRON MICROWAVE** 10-03
MAGNIFYING GLASSES 14-26
MAGNIFYING LAMPS 12-20, 14-27
MANGANESE BATTERY 11-02
MANUALS 14-66
MARINE
 ANTENNA 19-20, 19-24
 ANTENNA MOUNT BASE 19-25
 COMMUNICATION 19-03
 RADIO HOUSING / FACIA 19-06
 SPEAKER 19-06
MARKER PENS 14-20
MARSHAL TRANSFORMERS 01-40
MASKING TAPE 14-68
MASONRY DRILL BITS 14-81
MASTHEAD
 AMP HOUSING 09-18
 AMP POWER INJECT 09-18
 AMPLIFIER BOOSTER 09-18
 BALUN 09-03
 DIPLEXER 09-03, 09-21
 FILTERS 09-21
MATRIX
 COMPONENT 20-20
 HDMI 20-38
 IR 20-36
 SDI 20-36
MCX & MMCX
 ADAPTORS 07-35, 19-10
 PLUGS & SOCKETS 07-26, 19-09
MDTP BREAK OUT 08-06, 16-137
MEDIA
 AUDIO CASSETTE TAPE 05-20
 BLUE RAY BLANK DISKS 16-29
 CD / CDRW 05-20, 16-27
 CD / DVD CASES 05-21, 16-30
 CD ENVELOPES & SLEEVES 16-30
 DAT 05-20, 16-27
 DISK STORAGE 05-21, 16-31
 DVD 16-28
 FLOPPY DISK 16-27
 MICRO-CASSETTE 05-20
 MINI DISK 05-20, 16-27
 MINI DVD-R/RW 16-28
 PLAYERS 16-23, 20-02
 PRESENTER 16-09, 20-12
MEDIA CENTRE REMOTES 16-09, 20-12
MEDIA PLAYER ACCESSORIES 12-35, 16-19
MEDIA PLAYER BATTERIES 11-52
MEMBRANE CONNECTOR 05-09
MEMORY CARD PLAYER 16-14
MEMORY CARD READER 16-16
MEMORY CARDS & STICKS
 ADAPTORS 16-16
 CF 16-26
 MICRO SD 16-26
 MINI SD 16-26
 MS MICRO M2 16-26
 MS PRO DUO 16-26
 PLAYSTATION PS-1 & PS2 15-07
 PLAYSTATION STICK PSP 15-04, 16-26
 READER [USB] 16-16
 SD 16-26
 USB FLASH DRIVE 16-27
 XD 16-26
MEMORY STICK 16-26
MERCURY BATTERY 11-07
MERIT AUTOMOTIVE 07-19, 18-50
METERS
 AC CLAMP 14-55
 ANALOGUE 14-55
 APPLIANCE TEST 14-52
 CAPACITANCE 14-57
 DIGITAL MULTIMETER 14-54
 EMF 14-51
 FIELD STRENGTH [TV RF] 09-12, 14-50
 FREQUENCY COUNTER 14-53
 INSULATION 14-61
 LASER POWER 05-19, 14-53
 LCR 14-57
 LEADS 07-17, 14-62
 MICROWAVE LEAK 10-07, 14-51
 MOISTURE DETECTOR 14-53
 PEN DIGITAL 14-55
 SATELLITE 09-12, 14-50
 THERMOMETER 12-11, 14-51
 TV ANTENNA SIGNAL 09-12, 14-50
 VSWR & POWER 14-50, 19-15
MICA WASHERS 01-29
MICRO
 CASSETTE 05-20
 DRIVERS [TOOLS] 14-07
 FUSE 02-23
 PROCESSORS [IC] 01-25
 SWITCH 02-31, 10-08
MICRO-TEMP FUSES 02-23
MICROPHONE
 BODY PACKS 06-42, 06-45
 CABLE SHIELDED 13-03
 CABLE TESTER 06-28
 CARRY CASE 06-43
 CASSETTE 06-37
 CB RADIO 19-02
 CELLULAR PHONE 06-37, 17-05
 CHOIR 06-41
COMMS [AMATEUR / CB] 19-02
 COMPUTER 16-10, 16-12
 CONDENSER INSERT 06-37
 CURLY CORD 13-14, 19-02
 DESK 06-37, 06-41, 16-12, 19-02
 DRUM 06-39
 DVR 21-20
 DYNAMIC 06-37
 FM WIRELESS 06-39
 GOOSENECK 06-37, 06-39, 06-41, 16-12
 GROUND LOOP STOP 06-28
 GUITAR [PICK UP] 06-39
 HANDS FREE 06-37, 17-05
 HEADSET TYPE 06-39, 06-43
 HOLDER 06-36, 06-40
 HOLDER [CB] 19-02
 INDUCTION 06-37, 07-47
 INPUT CONTROL 06-28
 INSERTS 06-37
 INSERTS [CB] 19-02
 INSTRUMENT 06-39
 LAPEL 06-37
 LEADS 06-36, 08-21
 LEVEL CONVERTER 06-28
 MOBILE PHONE 06-37, 17-05
 PHANTOM POWER BOX 06-28
 PLUGS & SOCKETS 07-15, 07-39
 PRE-AMP 06-28
 PROFESSIONAL 06-38
 SPLITTER 06-28
 STANDS 06-36
 STEREO LAPEL 06-37
 VOX SWITCH 06-28
 WIND SCREENS 06-37
 WIRELESS FM MIC 06-39
 WIRELESS SYSTEMS 06-40
MICROSCOPE [USB CAMERA] 16-14
MICROWAVE
 APPLIANCE TEST 10-12
 BELTS 10-14
 CAPACITORS 10-14
 DIODES & HV PROTECT 10-09
 DOOR LINING 10-07
 FIXING NUTS [MAGNETRON] 10-07
 FUSES 02-23, 10-13
 GLASS TRAY 10-12
 GLOBES & LAMPS 10-10
 LEAKAGE TESTER 10-07
 LINER 10-07
 MAGNETRON 10-03
 MANUAL & INFO 10-14
 MOTORS 10-13
 NEON TESTER 10-07
 NUTS [MAGNETRON] 10-07
 OVEN & DOOR SWITCH 02-31, 10-08
 PANASONIC SMPS KIT 10-06
 ROOF LINER COVER 10-11
 TAMPER PROOF LABEL 10-07
 TESTING 10-07
 THERMAL CUT 10-12
 THERMISTOR 10-12
 TORX SECURITY SCREWDRIVER 10-07
 TRAY COUPLER 10-12
 VARISTOR 10-12
MID-WOOFER SPEAKERS 06-63
 DAI-ICHI HIFI 06-68
 PEERLESS 06-109
 SB ACOUSTICS 06-80
 SCAN SPEAK 06-91
 VIFA 06-103
MIDI LEADS 08-19, 16-131
MIDRANGE SPEAKERS
 DAI-ICHI 06-62
 HORN 06-75
 SB ACOUSTICS 06-79
 SCAN SPEAK 06-89
 VIFA 06-102
MINI CDR DISK 05-20, 16-27
MINI DISK
 RACK 05-21
 RECORDABLE 05-20, 16-27
 STORAGE 15-05
MINI TV ANTENNA ADAPTOR 07-32, 09-02
MINI/MICRO DVI ADAPTORS 08-05, 16-136
MIRRORS 14-26
MIXER, AUDIO 05-22, 06-28
MOBILE PHONE
 ADAPTORS 07-28, 17-24, 19-10
 ANTENNA 17-28, 19-31, 19-39
 ANTENNA LEADS 17-23, 17-26
 ANTENNA MOUNTS 17-33, 17-35
 ANTENNA [DIRECTIONAL] 17-34, 19-35
 ANTENNA [GLASS MOUNT] 17-28, 19-33
 BLUETOOTH ACCESSORIES 17-18
 BRACKETS [CAR] 17-16, 18-16
 BULL BAR BRACKET 17-35
 CAR CHARGER 17-03, 17-13
 CAR KIT 17-10
 CAR MOUNTING 18-16, 18-43, 18-52
 CAR STEREO INTEGRATE 17-05
 CASE LEATHER 17-22, 17-36
 CASE CLEAR 17-40
 CASE LONSDALE 17-39
 CHARGERS 17-02, 17-22, 17-48
 COMPUTER CONNECT 16-122, 17-47
 CONNECTOR PLUG 07-24, 07-34, 17-24
 CRADLES & HOLDERS 17-10, 18-17
 DA-SACK BUM BAG 17-43
 DATA CABLE FOR PC 16-122, 17-47
 DISMANTLING TOOLS 17-44
 DISPLAY STAND [SALE] 17-43
 DRIVESAFE 17-06
 EMERGENCY CHARGER 17-03, 17-49
 FLASHING ACCESSORIES 17-43
 GLASS THRU ANTENNA 17-28, 19-33
 GSM SIM CARD READER 17-44
 HAND STRAP 17-43
 HANDSFREE BLUETOOTH 17-05, 18-45
 HANDSFREE CAR KIT 17-06
 HANDSFREE PERSONAL 17-05
 HOLDERS [CAR] 17-14, 18-16
 IPHONE & IPAD ACCESSORIES 17-47
 IRDA INTERFACE 17-47
 LEATHER CASE 17-36
 MINI HANDS FREE 17-21
 MOUNT BRACKETS [CAR] 17-16, 18-16
 PATCH CABLE [ANT] 17-23, 19-12
 PLUGS 07-24, 17-25
 SIM ADAPTORS AND CUTTERS 17-44
 SIM CARD READER [USB] 16-16, 17-44
 SPEAKER 06-55, 17-05
 TOOLS 14-06, 14-08, 17-44
 TRAVEL CHARGER 17-02, 17-22, 17-48
 USB CHARGER 17-02, 17-13, 17-22
 USB DATA CABLE 08-25, 16-122, 17-47
MOD KITS, TV 03-07
MODEM
 ADAPTORS OVERSEAS 12-19
 ADSL 16-100
 DIAL UP 16-100
 LEADS [ETHERNET] 16-104
 LEADS [NULL-MODEM] 16-105
 SURGE PROTECTOR 12-10, 16-42
MODULAR
 ADAPTOR [TELEPHONE] 07-46, 16-102
 CABLE [PHONE] 07-46, 13-14, 16-103
 GENDER CHANGERS 07-46, 16-103
 TOOL 14-14, 16-78
MODULATOR
 RF 09-13, 09-17, 15-13
 VIDEO 20-56, 20-65, 21-44
MOISTURE DETECT METER 14-53
MONITOR
 12V BATTERY 11-32
 DOOR PHONE 21-02
 LCD-CAR 18-24, 21-09
 LEADS 08-13, 16-132
 MOUNTING 20-104
 REVERSING [CAR] 18-26, 21-33
 TEST PATTERN GENERATOR 14-48
MOTION SENSING LAMP 12-09
MOTOR
 CASSETTE 05-04
 CD & DVD 05-06
 MICROWAVE 10-13
 START CAPACITORS 02-07
 MOUNTING BLOCK 240V 12-16
 MOUNTING BRACKETS PC 16-20
 MOUNTING CAMERAS 21-30
 MOUNTING SPEAKERS 17-16, 18-16, 20-99
 MOUNTING WALL PLATE 07-43, 09-05, 12-17
MOUSE
 COMPUTER 16-02
MULTIMEDIA
 BREAK OUT BAYS 16-16, 16-20
 EARMUFFS 06-02, 14-21
 HEADSETS 06-07, 16-10, 16-90, 17-19
 MICROPHONE 06-37, 16-12, 16-101
 SPEAKER 06-10, 16-19, 16-124
 STORAGE 05-21, 16-30
MULTIMETER 14-54
MULTIMETER CASES 14-55
MULTIMETER LEADS 14-62
MUSIC ON HOLD 07-48
N
N TYPE
 ADAPTORS & CAPS 07-34, 17-24, 19-09
 ATTENUATOR 19-15
 PLUGS & SOCKETS 07-25, 17-25, 19-08
 ANTENNAS 19-28
 LEADS 19-13
 LIGHTNING ARRESTER 19-19
 SWITCH 19-15
 NEEDLE FILES 14-10
 NEEDLES [STYLUS] 05-26
 NEON LAMPS 02-20
 NEON LIGHT STICKS 18-28
 NEON MICROWAVE TESTER 10-07
 NETWORK MEDIA PLAYERS 16-23, 20-02
 NETWORK VIDEO RECORDER 21-63
 NETWORKING CABLES 16-104
 NETWORKING ETHERNET 16-84
 NETWORKING (LEVEL ONE) 16-84, 16-142
 NETURIK NEXUS CONNECT 07-02
 NIBBLING TOOL 14-19
 NICAD BATTERIES 11-15
 NIMH BATTERIES 11-12
 NINTENDO BATTERIES 11-51, 15-12
 NINTENDO DS & GB ACC 15-03
 NINTENDO Wii ACCESSORIES 15-02
 NIPPER PLIER 14-16
 NITRILE GLOVES 14-20
 NOISE FILTER / SUPPRESSOR 02-17, 12-14
 COMMUNICATION 17-04, 19-07
 NON INDUCTIVE RESISTOR 02-14
 NOONTEC 16-23, 20-02
 NOTEBOOK BATTERY [SEE LAP] 11-60
 NTSC TO PAL CONVERTER 20-66, 20-91
NUTS
 COMPONENT MOUNT 14-79, 18-53
 MAGNETRON 10-07
 NUTS & BOLTS 14-79
 NYLON BOLTS & WASHERS 20-91
O
OCTAL VALVE BASES 01-40
OFC [OXYGEN FREE CABLE]
 CABLE 13-01
 LEADS 08-02, 08-14, 08-22
OFFICE WIPES 14-72
OIL PEN 14-70
OMB TV SUPPORTS 06-46, 16-38, 20-92
OPTICAL
 AUDIO CONVERTER 08-03, 20-16
 CABLE SELECTOR 08-03, 20-18
 CABLE SPLITTER 08-03, 20-18
 LEADS 08-02, 08-15
OPTO COUPLER TOSLINK SOCKET 01-34
OSCILLOSCOPE LEADS / PROBE 14-62
OUTDOOR
 CAMERA HOUSINGS 21-23
 CAMERAS [SECURITY] 21-12, 21-18
 SPEAKER 06-12, 06-25
OVERCOAT PEN [PAINT] 14-70
OVERSEAS ADAPTORS 07-48, 12-19
P
PA AMPLIFIER
 HORN SPEAKER 06-24, 06-35, 06-55
 SPEAKER 06-46
 SYSTEM 06-27, 06-32
PABX MUSIC ON HOLD 07-48
PACK DIODE 01-31
PACKAGING TAPE & DISPENSE 14-68
PAD LOCK SECURITY CABLE 21-39
PAINT
 BRUSHES 14-74
 LOCKING 14-70
 PCB OVERCOAT PEN 14-70
 SILVER-CONDUCTIVE 14-70
PAL
 ANTENNA ADAPTORS 07-32, 09-02
 ANTENNA PLUGS/SOCKETS 07-23
 TO NTSC CONVERTER 18-44
 PAN & TILT 21-11
 PANASONIC KX-T3000 PARTS 09-09
 PANASONIC MWO INVERT KIT 10-06
 PANASONIC SPINDLE 05-09
 PANEL HOLE CUTTERS 14-81
PANEL MOUNT
 CIRCUIT BREAKER 02-27, 12-16
 FUSE HOLDER 02-27, 12-16
 PASSIVE RADIATOR SPEAKER 06-95
 PASSIVE RADIATOR SPEAKER 06-98
PATCH LEADS
 CELLULAR 17-23, 17-26
 ETHERNET 16-104
 TELEPHONE 07-46, 16-103
 WIFI 16-96, 19-12
PATHWAY LIGHTS INDOOR 12-09
PATTERN GENERATOR
 HDTV / DVI / VGA 14-48
 TV / VIDEO 14-48
PCB
 CLEANING BRUSHES 14-74
 CLEANING PEN 14-43, 14-74
 CONNECTORS AND MOUNTS 16-113
 FLAT WIRE CONNECTS 05-09
 PROTOTYPE 01-28
 REPAIR 14-44, 14-70
 TERMINAL BLOCKS 07-44
 PCI CARD 16-49, 16-53, 16-93, 16-130
 PCI CARD DVR 21-48
 PCMCIA 16-52
 PDA & PALM BATTERY 11-54
 PEARL CATCHER 14-09
 PEERLESS SPEAKER 06-107
PEN
 CONDUCTIVE 14-70
 DISPENSER 14-43
 FIBRE PCB CLEANING 14-74
 MARKER 14-20
 NINTENDO 15-03
 OIL 14-70
 PROTECTIVE PAINT 14-70
 TOUCH-SCREEN 15-03
 PEPI THERMAL SWITCH 02-18
 PHANTOM POWER [MIC] 06-28

- PHILIPS
BACKUP BATTERY 11-19
FLYWHEEL [CAR AUDIO] 05-04
SWITCHES 02-32
TV PARTS 03-02, 03-06, 03-10
- PHONO
ADAPTORS 07-28
CARTRIDGE 05-26
GAUGES 05-23, 14-25
INPUT PREAMP 05-22, 20-16
LEADS 07-13
LINE CONVERTER 05-22, 20-16
PLUGS & SOCKETS 07-03, 07-08, 07-13
RECORD CLEANING 05-24
STYLUS 05-26
WIRES [FOR CARTRIDGE] 05-23
- PHOTO
DIODE [VCR] 01-34, 04-21
FRAMES 16-15
IR DIODE 01-34, 04-21
OPTO COUPLERS 01-33, 04-21
TRANSISTOR 01-34
PICO FUSE 02-23
PICTURE TUBE SOCKET 03-04
PIEZO BUZZERS 06-54, 21-41
PILOT LAMPS 02-20, 14-26
PINCH ROLLER
AUDIO CASSETTE 05-04
PIR [SECURITY] 21-21, 21-42
PL259 & SO239
ADAPTORS 07-38, 19-10
END CAPS 07-38, 19-09
PLUGS & SOCKETS 07-27, 19-08
PLASMA SCREEN CLEAN 14-72, 16-76
PLASTIC BAGS 01-27
PLASTICS LUBE GREASE 14-71, 14-77
PLAYSTATION ACCESSORIES 15-04
PLAYSTATION BATTERIES 15-05, 15-07
PLAYSTATION REPAIR 05-08, 15-08
PLCC IC EXTRACTOR 14-11
PLIERS 14-18
PLUG PACK POWER 11-33, 12-34, 16-19
16-37, 17-02, 17-13, 21-03, 21-42
PLUG PACK [CUSTOMISABLE] 12-35, 12-49
PLUGS
ANTENNA [F & PAL] 07-23, 09-03
APPLIANCE 240VAC 12-14
BANANA 06-49, 07-16, 18-49
BNC 07-22, 16-11, 19-09
BNC & TNC PINS 07-27
CABLE TERMINATORS 07-24, 09-04
CAR ACCESSORY 07-19, 18-50
CB MICROPHONE 07-15, 07-39, 19-02
CIGARETTE LIGHTER 02-27, 07-19
CIGARETTE LIGHTER 17-04, 18-50
COAX CABLE JOINER 07-24, 17-25
COMMUNICATION 07-22, 19-08
COMPUTER 16-108, 16-114
CRIMP FERULES [RG58/59] 07-27, 17-25
DC 07-19, 12-49
DEANS 1300
DIN & MINI DIN 07-18
EAR 06-02, 14-21
EIAJ 07-21, 12-49
END CAPS 07-38, 19-09
FME 07-26, 17-25, 19-08
FUTABA CONNECTORS 11-21
IDC FLAT RIBBON 16-112
IEC 240VAC MAINS 12-14
JR CONNECTORS 11-21
LUCENT 07-26, 19-09
M259 MINI UHF 07-27, 19-08
MCX & MINI MCX 07-26, 19-09
MICROPHONE 07-15, 07-39, 19-02
MICROPHONE [CB] 07-15, 07-39, 19-02
N TYPE 07-25, 19-08
NEUTRIK 07-02, 07-13
PCB EDGE 16-113
PHONO 07-03, 07-08, 07-13
PL259 07-27, 07-38, 19-08
POWER 240VAC 12-10, 12-14
QUICK DISCONNECT 07-50, 18-58
RCA 07-10, 07-27
S-VIDEO 07-15, 07-18
SCART 07-15, 07-18
SMA & SMB 07-25, 19-08
TAMIYA 11-21
TERMINATOR 07-24, 09-04
TNC 07-26, 17-25, 19-09
TV ANTENNA 03-02, 07-23, 09-03
VIDEO RGB 07-15
POE 16-86, 16-93, 16-144
POLYESTER CAPS 02-06
POLYPROPYLENE CAPS 02-04
POLYSWITCH PROTECTOR 02-19
POP RIVETS & GUN 14-79
PORT SPEAKER [RESISTIVE] 06-97
PORT SPEAKER [TUBES] 06-50
PORTABLE
DOCUMENT SCANNER 16-08
PA SYSTEM 06-32
RADIO 20-07
SOLDERING 14-29
SPEAKERS 16-11, 17-50
VIDEO MONITOR 18-25, 21-09
POS DISPLAY STAND [MOB] 17-43
POTENTIOMETERS
CARBON 02-15
FOCUS [TV] 03-02
SWITCH-POTS 02-15, 03-02
TRIMMING 02-16
WIRE WOUND 02-15
POWER 240VAC
ADAPTORS 12-19
CABLE 12-15
CABLE CLAMPS 12-18
CABLE GROMMETS 12-15
CEILING ROSE 12-17
CIRCUIT BREAKER 12-16
CLAMP METER 14-55
DOUBLE ADAPTORS 12-09
EXTENSION CORD LOCK 12-13
EXTENSION CORDS 12-13
FUSE WIRE 12-15
ISOLATION TRANSFORMER 12-33
JUNCTION BOX 12-17
LAMPS 02-20
LEADS 12-12
MOUNT BLOCKS 12-16
MOUNT BRACKETS 12-17
PACKS [SEE POWER PACKS] 12-34
PLUGS & SOCKETS 12-14
POINTS 12-16
SAFETY 12-10
SURGE PROTECTOR 12-10
SWITCH 12-16
SWITCH [APPLIANCE] 02-32
TIMER SWITCHES 12-11
TRANSFORMERS 12-33
VARIAC 12-33
POWER BOARD
AUTO SWITCHED 12-05
DELUXE 12-04
RACK MOUNT 12-07, 16-42
SPACED SOCKETS 12-06
STANDARD 12-06
SURGE PROTECTED 12-05
SWITCHED 12-06
SWITCHED INDIVIDUALLY 12-05
TRAVELLERS 12-09
UPS 12-02
USB CHARGE 12-06
WORKSHOPS 12-08
POWER CABLE [DC 100V] 13-05, 13-10
POWER CABLE [DC 12V] 13-08
POWER PACKS
AC 12-35, 12-36
DC 12-34, 17-02, 21-43
GAME CONSOLE [PSP] 15-05
GAME CONSOLE [PS] 15-07
GAMEBOY 15-03
GPS 17-22
IPOD & MP3 12-35, 17-49
MULTI-VOLTAGE UNIVERSAL 12-35, 43
REVERSIBLE PLUG 12-38, 12-49
POWER SUPPLY
13.8 VDC 12-37, 12-52
ANTENNA INLINE 09-18
CAMCORDER 12-44
CCTV 21-43
COMPUTER 16-45
DISTRIBUTION AMP [RF] 09-18
DS & GAMEBOY 15-03
ISOLATION 12-33
KINGRAY 09-18
LAPTOP 12-43
PACKS 12-34
PLAYSTATION PS1/2/X 15-07
PLAYSTATION PSP 15-05
TRANSFORMERS 12-32
TRANSFORMERS [TV SMPS] 03-03
UNINTERRUPTIBLE 12V 12-52
UPS 12-02, 12-52
USB 12-35, 16-19
VARIABLE 12-37, 12-43
POWER TOOL BATTERY 11-68
POWER TOOL BATTERY CHARGE 11-79
POWER TOOLS 14-03
POWERED SPEAKERS 06-10, 06-29, 16-11
PRE PROGRAMMED REMOTES 20-10
PREPARED LEADS 08-01
PRINTER LEADS 16-121
PRINTER SERVER 16-85
PROBE
HV 14-47
LOGIC 14-61
OSCILLOSCOPE 14-62
PULSE 14-61
PROTECTOR
MICROWAVE DIODE 10-09
POWER SURGE [240VAC] 12-10
SPEAKER 02-19, 06-53
TELEPHONE & FAX 07-48, 12-10, 16-42
THERMAL 02-18, 02-23, 10-12
ROTOTYPE BOARDS 01-28
PS1 & PS2 ACCESSORIES 15-06
PS3 ACCESSORIES 15-07
PS3 BATTERY 15-12
PSP ACCESSORIES 15-04
PSP BATTERY 15-12
PTC RESISTOR 03-03
PUBLIC ADDRESS 06-25
AMPLIFIER 06-27, 06-32
ACTIVE SPEAKERS 06-29
CEILING WALL SPEAKERS 06-21
HORN SPEAKER 06-75
PORTABLE SYSTEMS 06-32
SWITCHES 06-26
WALL CEILING SPEAKERS 06-21
VOLUME CONTROL 06-26
PVC
SAW 14-16
TAPE 14-68
TUNER 02-03
Q
QUARTZ HALOGEN LAMP 02-20, 12-27
QUICK DISCONNECT
AUTOMOTIVE 07-50, 18-40, 18-58
GENERAL 07-45, 18-40
KIT 07-45, 18-40
R
RACING CAR BATTERY 11-20
RACK
AUDIO MIXER 06-29
CABINETS AND MOUNTS 16-81
CABINETS 10" 16-80
ETHERNET 16-84
KVM 16-57
MINI DISC STORAGE 05-21
MOUNT MODULATORS 09-17
MOUNT RF DISTRIBUTION 09-17
POWER BOARD 12-07
PRODUCTS 16-01
RJ45 PANEL 16-82
UPS 12-03
RADIO
AM/FM 06-02
DAB+ 20-07
PORTABLE & MANTLE 20-07
RADIO ANTENNA 19-01
CARAVAN & BOAT [FM] 19-20
CB 19-23
FM 19-20
MARINE 19-24
SCANNER 19-22
UHF 19-26
RADIO AUTOMOTIVE ACCESSORIES 18-01
RADIO DIAL STRING 13-17
RADIO FOR WORKSITE 06-02, 14-21
RADIO HOUSING PROTECTOR 19-06
RADIO INSTALLATION 18-13
RADIO REMOVAL TOOLS 18-56
RATCHET DRIVER 14-04, 14-07
RCA
ADAPTORS 06-09, 07-28
LEADS 08-14
PLUGS 07-10
SOCKETS 07-11
TERMINAL PANEL 07-10
REAR PRO TV PARTS 03-09
RECHARGEABLE
BATTERY 11-10
CORDLESS SCREWDRIVER 14-03
TORCHES 18-30
RECORD & PLAYBACK HEADS
AUDIO CASSETTE 05-05
RECORD CLEANER [VINYL] 05-24
RECORD PLAY SWITCHES 02-33
RECORD PLAYER
ACCESSORIES 05-22
BELTS 05-03
CARTRIDGES 05-26
HEAD SHELL 05-23
STYLUS 05-26
STYLUS CLEANER 05-24
RECORDABLE MEDIA
CD / CD-R / CD-RW 05-20, 16-27
DAT TAPES 05-20, 16-27
FLOPPY DISK 16-27
MINI DISC 05-20, 16-27
RECTIFIER
BRIDGE 01-31, 10-06
DIODE 01-32, 10-09
REED SWITCHES [DOOR] 21-40
REFERENCE
ACOUSTICS & SPEAKER 06-48, 14-66
CAMCORDER BATTERY CHARGER11-38
FBT & LOPT 14-66
MICROWAVE OVEN 10-14, 14-66
SEMICONDUCTOR 01-28, 14-66
TV DEFLECTION 03-08, 14-66
REFRIGERATOR LAMPS 02-22, 10-10
REGULATED POWER SUPPLY
13.8 VDC HIGH CURRENT 12-37
VARIABLE LAB SUPPLY 12-52
RELAYS 01-12, 02-28, 18-41
AUTOMOTIVE 02-28, 18-41
MINIATURE 02-28
REMOVER TOOL 02-27, 14-11
SOLID STATE 01-33
REMOTE CONTROLS
EXTENDER 20-54
FOXTEL 20-13
LEARNING 20-10
MEDIA CENTRE [PC] 16-09, 20-12
MEDIA PRESENTER 16-09, 20-12
PRE PROGRAMMED 20-10
REPAIR [MEMBRANE] 14-70
REPEATERS 09-14, 20-36, 20-54
REPAIR KIT
REMOTE CONTROL 14-70
TV 03-07
VCR 04-18
RESEAL PLASTIC BAGS 01-27
RESISTORS
DUMMY LOAD 4 Ohm / 8 Ohm 02-16
FUSIBLE 02-14
HIGH VOLTAGE & FOCUS 03-02
NON-INDUCTIVE 02-14
PTC 02-19
STANDARD 02-14
TUNING BLOCK 03-04
VARIABLE 02-15
WIRE WOUND 02-14
RESONATOR CERAMIC 02-16
RETRACTABLE KNIFE 14-15
RF
ATTENUATORS [TV] 09-02, 09-04
CHOKE 02-13
CONNECTORS 07-22, 17-25, 19-08
CONVERTER [AV] 09-13, 15-13, 20-65
CONVERTER [GAME] 15-07, 15-10, 15-13
CONVERTER [XBOX] 15-10
DISTRIBUTION 09-02, 09-15, 09-17
MODULATORS 09-13, 09-16
POWER & VSWR METER 19-15
SIGNAL METERS 09-12
RG11 COAX CABLE 13-07
RG174 COAX CABLE 13-06, 16-97, 17-27
RG213 COAX CABLE 13-06, 17-27, 19-14
RG316 COAX CABLE 13-06, 17-27, 19-14
RG58 COAX CABLE 13-06, 17-27, 19-14
RG59 COAX CABLE 13-04, 13-07, 21-44
RG6 COAX CABLE 13-07, 21-44
RGB
CABLE 13-05, 13-13
LEADS 08-13, 16-133
PLUG 07-15
RIGGER GLOVES 14-20
RING TERMINAL 07-17, 07-45, 18-40, 18-48
RIVETS & GUN 14-79
RJ45
ADAPTORS 16-84, 16-103
BOOTS 16-108
CRIMPING TOOL 14-14
LEAD TESTER 14-58
LEADS 16-104
PLUG 16-108
ROCKER SWITCHES 02-34
ROOF LINER [MICROWAVE] 10-11
ROUTER
ADSL 16-92, 16-100
WIRELESS 16-92
RS232
PROTECTOR 16-42
ADAPTORS 16-114, 16-120
CABLE 13-13, 16-112
EXTENDER 16-61, 16-66
USB CONVERTER 16-18, 16-121
RUBBER
DUCKY [ANTENNA] 19-22, 19-26
ADDED MATS 14-46
FEET 06-48
GLOVES 14-75
GROMMETS 13-17
KEYPAD REPAIR 14-70
TAPES 14-68
RULER [STEEL] 14-25
S
S-VIDEO
ADAPTORS 07-32, 08-23
CABLE 13-04
LEADS 08-02, 08-15, 08-23
PLUGS & SOCKETS 07-15, 07-18, 07-42
SWITCH BOXES 20-21
SAFETY GLASSES 14-21
SAFETY HATS 14-21
SAFETY PLUG [240V AC] 12-10
SAFETY SWITCH [RCD] 12-08
SAMSUNG TV POWER KITS 01-19, 03-07
SATA
ADAPTORS 16-18, 16-48
EXTERNAL CASES 16-22
HARD DISK 16-25
HARD DISK MOUNTING 16-20
SATELLITE
DISTRIBUTION AMP [RF] 09-05, 09-17
FINDER 09-12, 14-50
LINE AMP 09-05, 09-17
METER 09-12, 14-50
SPLITTER 09-04

- SAW
 FILTER 02-17
 RESONATOR 02-16
- SAWS
 GYROCK 14-15
 HACK 14-16
 HOLE 14-81
 PVC 14-16
 SB ACOUSTICS SPEAKERS 06-78
 SCAN SPEAK SPEAKERS 06-83
 SCANNER ANTENNA 19-22
 SCANNER PORTABLE DOCUMENT 16-08
 SCART
 CONVERTOR 07-32, 09-16, 20-81
 LEAD 08-12, 08-15
 PLUG & SOCKET 07-15
 SPLITTER BOX 08-12
 TO AV/S-VIDEO 07-32
 TO RGB/YUV 07-32, 08-12, 20-81
 SCISSOR CLAMP 14-09
 SCOPE SOLDERING 14-30, 14-35
 SCR & THYRISTOR 01-32
 SCREEN CLEANING 14-72
- SCREW
 ASSORTED 14-78
 CATCHER 14-09
 KIT 14-79
 SPEAKER MOUNT 06-46
 TRANSISTOR MOUNT 01-29
 SCREWDRIVER [TEST] 14-60
 SCREWDRIVERS 14-02
 SCREWDRIVERS [MICRO] 14-07
 SCRIBER 14-10, 14-74
 SCSI CONNECTIONS 16-117
 SD MEMORY CARD 16-26
- SDI
 CONVERTER 20-68
 MATRIX 20-36
- SEALED LEAD ACID BATTERY 11-28
- SECURITY
 ALARM ACCESSORIES 21-40
 ALARM BATTERY 11-28
 ALARM SYSTEM 21-36
 CABLE 13-05, 21-10, 21-44
 CABLE AND LOCK 21-39
 CABLE [CAMERA] 21-44
 CAMERA NIGHT VISION 21-12, 21-28
 CAMERA KITS 21-34, 21-44, 21-50
 CAMERA LENSES 21-23
 CAMERA MOUNTS 21-30
 CAMERAS PC 16-12, 16-142
 CAMERAS CAR 18-23
 CAMERAS SURVEILLANCE 21-10
 CCTV POWER SUPPLY 21-43
 COMBINATION LOCKS 21-39
 DOOR PHONE 21-06
 DOOR STRIKE OPENER 21-40
 DUMMY CAMERAS 21-29
 EMERGENCY SWITCH 21-40
 ENTRY ALARM 21-36
 INTERCOM 12-10
 KEY [PADS & SWITCHES] 21-38
 KEYBOARD CONTROL 21-11
 LABELS [TAMPER] 14-69
 LIGHT TIMERS 12-11, 21-39
 LIGHTING IR 21-28
 LOCK & KEY SWITCHES 21-40
 MAINS POWER TIMERS 12-11, 21-39
 MONITOR [LCD] 18-25, 21-09
 PAN & TILT 21-10, 21-22
 PIR 21-21, 21-38, 21-42
 RECORDERS 16-12, 16-142, 21-25
 SECURE CABLE & LOCK 21-39
 SIRENS & STROBES 21-41
 SMOKE ALARM 21-42
 SYSTEM CONTROLLERS 21-11
 TAMPER SWITCHES 21-40
 VIDEO DOOR PHONE 21-02
 VIDEO RECORDER 21-48
 VIDEO TRANSMISSION 09-13, 09-16
 VIDEO TRANSMISSION 20-21, 20-56
 VIDEO TRANSMISSION 21-45
 WARNING SIGNS 21-39
 WEATHER HOUSING 21-05
 WIRELESS CAMERA 21-34
- SELECTOR SWITCH
 AUDIO-VIDEO 08-03, 20-18, 20-30, 20-36
 OPTICAL CABLE 08-03
 RECORD-PLAY [TAPE DECK] 02-33
 SPEAKER 06-26
 SELF AMALGAMATING TAPE 14-68
 SEMICONDUCTORS 01-03
 DATA 01-28, 14-66
 SUBSTITUTION 14-66
- SENDER
 AUDIO-VIDEO 09-13, 20-64
 REMOTE 09-14, 20-54
 SERIAL RS232 LEADS 16-120
 SERVICE AIDS 14-42
 AEROSOLS 14-76
 SERVICE MANUALS 14-66
 SET TOP BOX 20-07
 SET TOP BOX & RECORDER 20-07
 SEWING MACHINE LAMPS 02-22, 10-10
 SIDE CUTTERS 14-16
- SILICON WASHERS 01-29
 SILICONE COMPOUNDS 14-70, 14-76
 SILICONE SEALANT 14-70
 SILVER
 CONDUCTIVE EPOXY 14-44, 14-70
 CONDUCTIVE PAINT 14-44, 14-77
 SIM ADAPTORS AND CUTTERS 17-44
 SIM CARD READER 16-16, 17-44
 SIM CARD READER [USB] 16-16, 17-44
 SIRENS & STROBES 06-54, 21-41
 SLA BATTERY 11-28
 SLA BATTERY CHARGERS 11-32, 12-52
 SLIDE SWITCHES 02-33
 SLOW BLOW FUSES 02-23
- SMA
 ADAPTORS 07-28, 07-34, 17-23, 19-10
 PLUGS & SOCKETS 07-25, 19-08
- SMB
 PLUGS & SOCKETS 07-25, 19-08
- SMOKE ALARM BATTERY 9V 11-03
 SMOKE ALARM TEST SPRAY 14-76, 21-42
 SOCKET & WRENCH SET 14-03, 18-56
- SOCKETS
 AC POWER 240VAC 12-14
 ANTENNA 03-02, 07-23, 09-03
 ANTENNA [CAR] 07-39, 18-75
 BANANA 07-16, 07-43
 BAYONET LAMP 240VAC 12-17
 BETA CAMERA 07-15
 BNC 07-23
 CAR ACCESSORY 18-50
 DC JACKS PCB MOUNT 07-18
 DC POWER 07-18
 DEANS 1300 ULTRA 11-21
 DIN & MINI DIN 07-15, 07-18, 16-115
 DVI & VGA 07-41, 16-112
 ETHERNET 07-41, 07-48, 09-06, 16-109
 F TYPE 07-43, 09-04
 FME 07-26, 19-08
 FUTABA 11-21
 HDMI 07-03, 07-41, 16-137
 I.C. 01-30
 JR 11-21
 MCX & MINI MCX 07-26, 19-09
 MICROPHONE 07-15, 07-39, 19-02
 N TYPE 07-25, 19-08
 NEUTRIK 07-02
 RCA 07-10
 S-VIDEO 07-15, 07-18
 S259 07-27, 17-25, 19-08
 SCART 07-15
 SMA & SMB 07-25, 19-08
 SO239 07-27, 19-08
 TELEPHONE 07-41, 07-47, 16-109
 TNC 07-26, 19-09
 TV ANTENNA 03-02, 07-23, 09-03
 TV PICTURE TUBE 03-04
 USB PANEL MOUNT 16-18
 USB PCB 16-114
 USN WALL MOUNT 09-07
 VALVE 01-40
 WALL MOUNT 07-41, 09-03, 09-07
- SOLDER
 60/40 14-42
 AID TOOLS 14-44, 14-74
 FLUX 14-43, 14-74
 FUME EXTRACTOR 14-42
 HEAT SINK COMPOUND 14-70, 16-71
 IC TOOLS 14-11, 14-44, 16-78
 LEAD FREE 14-42
 PASTE 14-44
 REMOVAL PISTOL / STATION 14-39
 REMOVAL SUCKER / WICK 14-45
 SMD REMOVAL 14-44
- SOLDERING IRON
 ACCESSORIES 14-36, 14-42, 14-74
 BATTERY POWERED 14-31
 FUME EXTRACTOR 14-42
 GAS 14-29, 14-32
 GENERAL PURPOSE 14-30
 PORTABLE 14-31
 STATIONS 14-33
 SOLID STATE DISK 16-25
 SOLID-STATE RELAY 01-33
 SOUND DEADENING MATERIAL 06-50, 18-13
 SOUND LEVEL METER 05-19, 14-53
- SPADE
 CONNECTORS 07-17, 07-45
 TERMINALS 18-40, 18-49
 SPANNER [ADJUSTABLE] 14-19, 18-56
- SPEAKER
 100V CEILING 06-22
 100V HORN 06-24
 100V TRANSFORMER 06-24
 2-WAY 06-15, 06-30, 06-122
 2.1 SYSTEM & 5.1 SYSTEM 06-10, 16-11
 ADAPTOR PLATE 18-08
 AMPLIFIED 06-10, 06-29, 17-50
 ATTENUATOR VOLUME 06-26, 20-59
 BASS REFLEX PORT 06-50
 BATTERY OPERATED 06-10, 17-50
 BLUETOOTH 06-30, 20-62
 BOOKSHELF 06-12, 06-122
 BOX CARPET 06-50, 18-13
 BOX LINING 06-50, 18-13
- BOX PORTS 06-50, 18-12
 BOX TERMINALS 06-49, 07-16, 18-12
 BOXES 06-59, 06-122, 18-10
 BRACKETS [MOUNT] 06-47, 20-99
 BUZZER 06-54, 21-41
 CABLE 13-10
 CABLE [100V] 13-05
 CAR 06-57, 18-02
 CEILING 06-16
 COMMUNICATION 06-55, 17-05, 19-06
 COMPACT 06-11, 06-55, 06-102
 COMPUTER 16-11, 16-91, 06-30
 CONNECTOR [NEUTRIK] 07-02
 CROSSOVER COMPLETE 06-51, 18-12
 CROSSOVER PARTS 06-51, 18-51
 CUBE 06-11, 06-58, 18-06
 DAMPENING MATERIAL 06-50, 18-13
 DUAL CONE 06-57, 06-62
 FEET 06-48
 FLOOR STANDS 06-46, 20-99
 FLOOR TRI-PODS [PA] 06-46
 GASKET TAPE 14-69
 GP REPLACEMENT 06-55, 06-60
 GRILLE CLIPS 06-50
 GRILLE CLOTH 06-50, 18-13
 GRILLE [AUTO] 06-67, 18-08, 18-13
 GRILLE [CEILING] 06-24, 06-67
 HORN 06-55, 06-75
 HORN [100V] 06-24
 HORN [PA] 06-55, 19-06, 21-41
 INSTRUMENTAL 06-74
 KITS 06-122
 LEADS 13-09
 LINE [100V] 06-21
 MAG SHIELD - DAI-1CHI 06-62
 MAG SHIELD - PC 06-10, 16-11
 MAG SHIELD - TV 06-56
 MAG SHIELD - VIFA 06-101
 MARINE 06-58, 19-06
 MEGAPHONE HORN 06-35
 MID RANGE DAI-1CHI 06-62
 MID RANGE SB ACOUSTICS 06-79
 MID RANGE SCANSPEAK 06-89
 MID RANGE VIFA 06-102
 MID WOOFER DAI-1CHI 06-63
 MID WOOFER DAI-1CHI HIFI 06-68
 MID WOOFER PEERLESS 06-109
 MID WOOFER PEERLESS KIT 06-127
 MID WOOFER SB ACOUSTICS 06-80
 MID WOOFER SCAN SPEAK 06-91
 MID WOOFER VIFA 06-102
 MINI 06-11
 MOUNTING 06-47, 20-99
 MULTIMEDIA 06-10, 16-11
 OUTDOOR 06-12, 06-25
 PA 06-21, 06-74
 PA AMPLIFIED 06-32
 PA HORN [100V] 06-24
 PA SYSTEM 06-27
 PASSIVE RADIATOR 06-95, 06-98
 PASSIVE RADIATOR KIT 06-129
 PATIO 06-12
 PIEZO 06-54, 06-75
 PLASTIC PLATE 18-13
 POLARITY TESTER 06-132
 PORT 06-50, 06-97
 PORTABLE 06-11, 06-58, 18-06
 PROJECTS 06-48
 PROTECTOR [POLYSWITCH] 06-53
 REAR BAFFLE 06-67, 18-09
 REFERENCE 06-48
 SCREWS 06-49, 14-78
 SELECTOR SWITCH 06-26
 SIREN 06-54, 21-41
 SOUND BAR 20-15
 SPEAKON TYPE PLUGS 07-02
 SPACERS 06-59
 SPIKES 06-48
 STANDS 06-46
 SUB WOOFER 06-01, 18-02
 SUB WOOFER AMP 06-31
 SUB WOOFER CAR 18-02
 SUB WOOFER BOX 06-128, 18-13
 SUB WOOFER TYMPHANY 06-120
 SUB WOOFER X-OVER 06-48, 06-51
 TERMINAL 06-49
 TO RCA CONVERTER 06-48, 18-42
 TV 06-56
 TWEETER - DAI-1CHI 06-60, 06-72
 TWEETER - FOUNTEK 06-76
 TWEETER - PEERLESS 06-107
 TWEETER - SB ACOUSTICS 06-78
 TWEETER - SCAN SPEAK 06-83
 TWEETER - VIFA 06-99
 USB DESKTOP 06-10, 16-11
 VOLUME WALL PLATE 06-26, 20-59
 WALL 06-16
 WALL BRACKET 06-47, 20-99
 WALL MOUNT 06-15, 06-24
 WIDE RANGE 06-57, 06-68, 06-102
 WIRE & CABLE 13-10
 WOOFER - DAI-1CHI 06-64, 06-71, 06-73
 WOOFER - PEERLESS 06-114
 WOOFER - SB ACOUSTICS 06-80
 WOOFER - SCAN SPEAK 06-95
- WOOFER - VIFA 06-106
 SPIN MOTORS [CD/DVD] 05-08, 15-08
 SPIRAL WIRE WRAP 13-17, 18-54
 SPIRIT LEVEL 05-23, 14-25
- SPLITTER
 ANTENNA 09-03
 BOOSTED ANTENNA 09-02, 09-05, 09-18
 CAR ACCESSORY POWER 18-37
 COMPOSITE VIDEO 20-21, 21-31
 DC POWER CABLE 07-20, 12-48
 DISPLAYPORT 20-24
 DVI 16-62, 20-23
 DVI CABLE 08-05, 16-135
 HDMI 20-23, 20-26, 20-34
 SATELLITE 09-04
 SCART 08-12
 TOSLINK OPTICAL 08-03
 VGA 16-60, 20-22
 YUV 20-21
- SPRAYS 05-18, 14-70, 14-76, 16-71
- SPRING
 ANTENNA BASE 19-17
 SSD [SOLID STATE DRIVE] 16-25
- STANDS
 DESK MIC 06-37
 MICROPHONE 06-36
 PS2 15-07
 SOLDERING IRON 14-43
 SPEAKER 06-46, 20-99
 TRIPOD [SPEAKER] 06-46
 TV 20-99
 STARTERS [FLUORO LAMP] 12-26
 STEERING WHEEL [XBOX] 15-09
 STICKY TAPE 14-68
 STRAIN RELIEF [CABLE] 13-17
 STRIPPER [WIRE & CABLE] 14-15
 STRIPS [TAG] 06-51, 18-51
 STRIPS [TERMINAL] 07-45, 12-18
 STROBE LIGHT [CAR] 12-56, 18-30, 18-57
 STROBES 06-54, 21-41
 STUD FINDER 14-60
 STYLUS 05-26
 STYLUS - STANFIELD CATALOGUE 05-29
 STYLUS CLEANER 05-24
- SUBWOOFER
 AMPLIFIER 06-31, 06-128
 CABINETS 06-59, 18-10
 CAR 18-02
 CROSSOVER 06-48
 KIT 06-128
 SPEAKERS 06-01, 18-04
 SUPER BRIGHT LED 01-35
 SUPER GLUE 14-71
- SURFACE MOUNT DEVICE [SMD]
 5V REGULATOR 01-30
 ASSIST TOOLS 14-10, 14-44
 CAPACITOR 02-11
 DESOLDER / REMOVAL 14-44
- SURGE PROTECTOR
 ARRESTER [GAS DC] 02-17
 ARRESTER [LIGHTNING] 19-19
 DELUXE 12-04
 MAINS POWER [240VAC] 12-06, 12-10
 TELEPHONE 07-48, 12-10, 16-42
- SWABS & APPLICATORS 14-75
- SWITCH
 02-30, 10-08, 21-40
 ANTENNA [COMMS] 19-15
 APPLIANCE [TV ETC] 02-32
 AUDIO/MIC VOX 06-28
 BUTTON 02-30
 CARLING 02-35, 18-50
 CENTRE OFF 01-42, 02-34
 EMERGENCY 21-40
 FOOT 01-42, 02-31
 GENERAL PURPOSE 01-42, 02-34
 ILLUMINATED 02-35, 18-50
 KEY 02-33, 21-40
 KICK 01-42, 02-31
 KNOB 01-42, 02-29, 04-22
 LAMP 02-31
 LEVER 02-30, 10-08
 MAINS POWER 12-16
 MICRO 02-31, 10-08
 MICROWAVE 02-31, 10-08
 MOMENTARY 02-30
 PEPI THERMAL 02-18
 POWER [APPLIANCE] 02-32
 POWER [MAINS] 12-16
 PUSH 02-30
 RECORD/PLAY 02-33
 ROCKER 02-34
 SPEAKER SELECT 06-26
 TACT 02-30
 TAMPER 02-31, 21-40
 THERMAL CUT 02-18, 02-23, 10-12
 TIMER [MAINS] 12-08, 12-11, 21-39
 TOGGLE 02-34
 TV POWER 02-32
- SWITCH BOX
 AV 20-18, 20-30
 COMPUTER 16-56
 DVI 16-63, 20-30
 HDMI 16-64, 20-31
 SPEAKER 06-26
 VGA 16-56, 16-61, 20-22

SWITCH MODE
REPAIR KIT [TV] 03-07
START UP PTC 03-03
TRANSFORMER TV PWR 03-03

SYRINGE
BOTTLE 14-43, 14-74
FLUX / SOLDER PASTE 14-44

T

TACKLE BOX TRAYS 14-24, 14-79
TACT SWITCHES 02-30
TAG STRIP 06-51, 18-51
TAMIYA CONNECTORS 11-21
TAMPER
LABELS 14-69
PAINT 14-70
SWITCH 02-31, 21-40
TANTALUM CAPACITORS 02-05
TAPE
BUTYL RUBBER 14-68
CASSETTE 05-20
DAT 05-20, 16-27
DISPENSER 14-68
DOUBLE SIDED 14-69
DUCT 14-68
FOAM 14-69
GAFFER 14-68
GASKET 14-69
HEAD CLEAN 05-20
HEADS [AUDIO] 05-05
HEAT SHRINK 14-68
INSULATION [PVC] 14-68
MASKING 14-68
MEASURE 14-25
MICRO-CASSETTE 05-20
PACKING 14-68
PLAYER BELTS 04-11
PVC 14-68
SELF AMALGAMATING 14-68
STICKY 14-68
TEST [AUDIO] 05-19, 14-67
TELEPHONE
ADAPTOR 07-41, 07-46, 07-49
ADSL ACCESS 07-46, 07-49, 16-102
ANSWER MACHINE ADAPTOR 07-46
CABLE 07-46, 13-14, 16-103
CABLE TEST & TRACE 14-61
CURLY CORDS 07-46, 16-103
EXTENSION BELL 07-49
EXTENSION CABLE 07-46, 16-103
EXTENSION REEL 07-47
GENDER CHANGES 07-46, 16-103
HANDSET 07-49
HANDSET CORDS 07-46, 16-103
LEADS 07-46, 16-102
MODEM ADAPTOR 07-48, 16-103
MUSIC ON HOLD 07-48
PLUGS 07-46
PLUGS [MODULAR] 16-102, 16-108
PRIVACY SWITCH 07-46, 16-102
RINGERS 07-49
RJ11/RJ45 KIT 16-102, 16-123
SOCKET 07-47, 16-109
SOLDERLESS TERMINALS 07-47
SURGE PROTECTOR 07-48, 12-10
TECHNICIANS TEST 14-51
TWIST STOPPER 07-48
VOIP 16-101
WALL MOUNT 07-48
WALL PLATE & SOCKET 07-41, 07-47
TELESCOPIC ANTENNA 09-08
TEMPERATURE SENSORS 02-18, 10-12
TEMPEST TV 12V PSU BLK 03-07
TERMINAL
BLOCKS 07-44, 12-18
JOINER & SPLICER 07-45, 18-40
RING 07-17, 07-45
SPADE 07-17, 07-45
SPEAKER 06-49, 07-16
STRIP 07-45, 12-18
TERMINATOR
BNC 07-22
F PLUG 07-24, 09-04
TEST
CASSETTE [AUDIO] 05-19, 14-67
CASSETTE [VIDEO] 14-24
CASSETTE [CLEAR VHS] 04-24, 14-49
CD 05-19, 14-67
LCR DECADE BOXES 14-59
LEADS 07-17, 14-63
LOGIC 14-61
PATTERN GENERATORS 14-48
SCREWDRIVER [AC] 14-60
TELEPHONE [BUTTKINSI] 14-51
VHS VCR ALIGN TAPES 04-24, 14-49
TESTER
ANTENNA VSWR 14-50, 19-15
APPLIANCE 14-52
BATTERY 11-02
CABLE TRACE & IDENTIFY 14-61
EHT TRANSFORMER 03-06, 14-47
ETHERNET CABLE 14-58, 16-79
HDMI 14-49

INSULATION MEGA-OHM 14-61
LASER POWER 05-19, 14-53
LOPT 03-06, 14-47
MICROWAVE 10-07, 14-51
MOISTURE 14-53
RJ45 & BNC NET CABLE 14-58, 16-79
SMOKE DETECTOR 14-76, 21-42
SOUND LEVEL 05-19, 14-53
SPEAKER POLARITY 06-132
VOLTAGE 12-54, 14-60
THERMAL
BREAKER 02-18, 02-23, 10-12
CUTOFF 02-18, 02-23, 10-12
FUSE 02-18, 02-23
SENSOR 02-18, 10-12
SWITCH 02-18
TRANSFER COMPOUND 14-70
THERMISTOR 02-18, 02-23, 10-12
THERMISTOR [MWO] 10-12
THERMOMETER 12-11, 14-51
THYRISTORS 01-19, 01-32
TIMERS [240VAC] 12-11
TNC
ADAPTORS 07-28, 07-34
PLUGS & SOCKETS 07-26, 19-09
TOGGLE SWITCHES 02-34
TOOL
1/4 HEX 14-04
AC VOLTAGE DETECTOR 12-54, 14-60
ADJUSTABLE WRENCH 14-19, 18-56
AIR COMPRESSOR 18-57
ALIGNMENT DRIVER 14-08
ALLEN KEYS 14-10
ANTENNA WRENCH [CAR] 18-56
ASSORTED HAND ASSIST 14-10, 14-74
BLOW TORCH 14-29
BOX 14-24, 14-79
BRUSHES [CLEANING] 14-74
CABLE PULLER 14-22
CABLE STRIPPER 13-17, 14-15
CABLE TIE GUN 13-15, 14-09
CALIPERS 14-25
CASE 14-24, 14-79
CAULKING GUN 14-19
CEILING CUTTER 14-15, 14-81
CERAMIC DRIVER 14-08
CLAMP SEIZER 14-09
CLAW HAMMER 14-19
COAX STRIPPER 13-17, 14-15
COMBINATION SET 14-06, 14-11
COMPUTER ETHERNET 14-14, 14-58
CONDUIT CUTTER 14-15
CORDLESS SCREWDRIVER 14-03
CRIMPING 14-12
CUTTER 14-15, 14-69
DEGAUSSING WAND 03-05, 14-47
DESOLDERING 14-39, 14-44
DRILL BITS & CHUCKS 14-80
ETHERNET 14-14, 14-58
FINDER [STUD & ACV] 12-54, 14-60
FUSE REMOVER 14-11
GLOVES 14-20
GLUE GUN & STICKS 14-29
GYPROCK SAW 14-15
HACK SAW 14-16
HAMMER 14-19
HANDY TOOL KIT 14-11
HEAT GUN 14-29
HELPING HANDS 14-19, 14-27
HERBIE CLIP 13-20
HEX DRIVERS & BITS 14-04
HEX KEYS 14-10
HIGH VOLTAGE PROBE 14-47
HOLE SAW 14-81
IC HANDLING 14-10
IDC PUNCH DOWN 14-15
IMPACT WRENCH [12V] 18-57
INSPECTION CAMERA 14-82
INSPECTION LAMP 14-26
INSULATED DRIVERS 14-02
JEWELLER SCREWDRIVER 14-07
JIGSAW BLADES 14-80
KITS 14-02, 14-07, 14-11, 14-24, 14-81
KNIFE 14-15
LASER LEVELLING 14-25
LOGIC PROBE 14-61
MAGNIFIER 14-26
MAGNIFYING DESK LAMP 14-27
MIRROR 14-26
MOBILE PHONE 14-08, 17-44
MODULAR CRIMP 14-14
MOISTURE DETECTOR 14-53
NEEDLE FILE 14-10
NIBBLING 14-19
PEARL CATCHER 14-09
PHONO SERVICE 05-23, 14-25
PLCC IC EXTRACTOR 14-11
PLIERS 14-18
POP RIVET GUN 14-19
PVC SAW 14-16
RULER 14-25
SAFETY GLASSES 14-21
SAFETY HATS 14-21
SCISSOR CLAMP 14-09
SCREWDRIVERS 14-02

SCRIBER 14-74
SIDE CUTTER 14-16
SOCKET & WRENCH 14-03
SOLDER REMOVAL 14-39
SOLDERING FUME EXTRACTOR 14-42
SOLDERING IRONS 14-30
SPIRIT LEVEL 14-25
SQUARE & LEVEL 14-25
STUD FINDER 12-54, 14-60
TAPE MEASURE 14-25
TEST SCREWDRIVER 12-54, 14-60
TORX & TRI-WING 14-06
TURNTABLE 05-23, 14-25
TWEEZERS 14-09
VCR SERVICE 04-23
VICE 14-19
VIDEO HEAD EXTRACT 14-10
VOLTAGE FINDER 12-54, 14-60
WALLET 14-11
WIRE STRIPPER 13-17, 14-15
WIRE WRAPPER 14-11
TORCH
BICYCLE 12-56, 14-28
BLOW [HEAT] 14-29
DIVING & SCUBA 12-58
FLASHLIGHT 12-56
GLOBES 02-20, 14-26
LED 12-56, 14-28, 18-30
MINERS 12-56, 14-28
TOROIDAL TRANSFORMER 240V 12-33
TORX 14-06
TOSLINK ADAPTORS & LEADS 08-02, 20-18
TOSLINK CABLE SELECTOR 08-03, 20-18
TOSLINK SPLITTER 08-03
TOWER SPEAKERS 06-124
TOY CAR BATTERIES 11-20
TRANSFORMER
240VAC TO 115VAC 12-19
AC GENERAL PURPOSE 12-32
EHT 03-03, 03-10
FENDER 01-40
FUSES 02-18, 02-23
HIGH VOLTAGE [TV] 03-03, 03-10
ISOLATION 14-47
LINE [100V] 06-24
LOPT 03-03, 03-10
MARSHAL 01-40
MULTI-VOLTAGE 12-32
STEP DOWN 240-115V 12-19
SWITCH MODE [TV] 03-03
TOROIDAL 12-33
VARIAC 14-47
TRANSIENT SUPPRESSOR 02-19
TRANSISTOR 01-03
MOUNTING 01-29
PHOTO 01-33, 04-21
SELECTOR 01-28, 14-66
TRANSMITTER
AV OVER TWISTED PAIR / CAT5 20-56
BLUETOOTH 20-62
IR DIODE MODULES 20-55
SECURITY CAMERA 21-35, 21-44
TRAP CERAMIC 02-17
TRAVEL
BATTERY CHARGERS 11-10, 11-32
CLOCK 12-11
GPS 17-22
MODEM ADAPTORS 07-48, 12-19
PC ACCESSORIES 16-123
POWER ADAPTORS 12-19
POWER BOARD 12-09
SCANNER 16-08
USB ACCESSORIES 06-123
USB CHARGERS 12-35, 16-19
TRAY [MICROWAVE OVEN] 10-12
TRI-COLOUR LED 01-34
TRI-WING SCREWDRIVER 14-06
TRIACS 01-32
TRIMMER CAPACITORS 02-03
TRIMMER POTS 02-16
TRIPLERS [TV] 03-06
TRIPOD [MICROPHONE] 06-36
TRIPOD [SPEAKER] 06-46
TUBE
CRT SOCKET 03-04
DEGAUSSING 14-47
VALVE SOCKET 01-40
VALVES 01-36
TUBING HEAT SHRINK 13-18
TUNER
AM-FM RADIO 02-03
PCI & USB 16-17, 16-54
TV 03-02
UHF-VHF UNIVERSAL 03-02
TUNING
BLOCKS [VR] 03-04
CAPS 02-03
GANG 02-03
TRACKS [PHILIPS] 03-02
TURNTABLE
ACCESSORIES 05-23
BELT 05-03
CARTRIDGES 05-26
GAUGES 05-23
STYLUS 05-26

TV
75 OHM TUNER 03-02
ANTENNA BALUN 09-02, 09-08
ANTENNA BOOSTER 09-05, 09-18
ANTENNA CABLE 13-07, 21-44
ANTENNA INDOOR 09-08
ANTENNA LEADS 08-29
ANTENNA OUTDOOR 19-21
ANTENNA SIGNAL STRENGTH 09-12
ANTENNA SPLITTER 09-02
ATTENUATORS 75 OHM 09-02
ATTENUATORS "F" 09-04
AV TO RF CONVERTER 09-13, 19-16
AV TO RF RESI-LINX 20-63
BALUN INLINE 09-02, 09-08
BALUN MASTHEAD 09-03
BAND SEPARATOR 09-02
BOOSTED SPLITTER 09-02, 09-18
BRACKETS & STANDS 20-92
CABLE [ANTENNA] 13-07
CABLE [AV] 13-04
COMPUTER CARD 16-54
CRT SOCKETS 03-04
DEFLECTION REFERENCE 03-08
DEFLECTION YOKES 03-04
DEGAUSSING WAND [CRT] 03-05, 14-47
DISTRIBUTION AMP RF 09-17
FAULT MANUALS 04-23, 14-66
FILTER [ALL IN ONE] 09-21
FILTER [FM] 09-21
FLYLEADS 08-29
FOCUS POTS & RESISTORS 03-02
GAME AV SELECT 15-14
IKON MANUAL 04-23, 14-66
INDOOR ANT 09-08
INTERNET SMART BOX 20-04
LINEARITY COIL 03-03
MANUALS 14-66
MASTHEAD BALUN 09-03
MOD KITS 03-07
MODULATORS 09-13, 09-17, 20-64
PAL ENTRY BOX [ANT] 07-43, 09-03
PAL SPLITTER [ANT] 09-03
PAL TO NTSC 20-66, 20-91
PATTERN GENERATOR 14-48
PLUGS [ANTENNA] 07-23, 09-03
PTC 03-03
REMOTE CONTROLS 20-10
RESI-LINX 20-63
SATELLITE LINE AMP 09-05, 09-17
SCART LEADS 08-12, 08-15
SET TOP BOX 20-07
SET TOP RECORDER 20-07
SIGNAL STRENGTH METER 14-50
SOCKETS ANTENNA 03-02, 07-23, 09-03
SOCKETS AV 07-41, 09-05, 16-112
STEREO MODULATORS 09-17, 21-31
SWITCHMODE TX 03-03
TELESCOPIC ANTENNA 09-08, 09-10
TEST INSTRUMENTS 03-05, 14-47
TUNERS [PCI & PCIe & USB] 16-54
TUNERS [SPARE PARTS] 03-02
TUNING BLOCKS 03-04
VARISTOR [SHARP] 02-19, 03-03
VIDEO WALL 20-14
WALL PLATE [ANTENNA] 07-43, 09-04
YOKES 03-04
TWEETER
DAI-1CHI 06-60
DAI-1CHI HIFI 06-72
DAI-1CHI PA 06-75
FOUNTEK RIBBON 06-76
HORN 06-75
PEERLESS 06-107
SB ACOUSTICS 06-78
SCAN SPEAK 06-83
VIFA 06-99
TWEEZERS 14-09
TWO WAY RADIO BATTERY 11-64
TYMPHANY SUB WOOFERS 06-120
TYRES [IDLER]
AUDIO 05-04
VIDEO 04-08

U

UHF
ANTENNA [COMMS] 19-26
COAX CABLE 13-06
WHIP ANTENNA 19-05
UNIDEN RADIO DC LEAD 19-27
UNIVERSAL
AUDIO AMP MODULE 01-26
BATTERY CHARGER 11-10, 11-21
CABLE STRIPPER 13-17, 14-15
PCB-PROTOTYPE 01-28
POWER PACK 12-34
POWER PLUGS INTERNATIONAL 12-19
REMOTE CONTROLS 20-10
TRAVELLER PLUGS 12-19
UPPER DRUM ASSEMBLY VCR 04-02
UPS [UNINTERRUPTIBLE POWER SUPPLY]
12V DC 11-33
240V AC 12-02

